


# CellVoice 4 / Trap Relay LT

**USER MANUAL**

**D-PK-CELLV**



Visit our website at [www.dpstelecom.com](http://www.dpstelecom.com) for the latest PDF manual and FAQs.

## Revision History

---

August 11, 2015	Rapid Response Monitoring Added
Novemeber 10, 2014	Added TrapRelay LT Option
February 28, 2014	Added "Setup" Section
January 2, 2014	Added Provisioning Web Timeout
July 26, 2013	Updated Wireless Modem Activation process
March 12, 2013	Initial Release

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied without prior written consent of DPS Telecom.

All software and manuals are copyrighted by DPS Telecom. Said software and manuals may not be reproduced, copied, transmitted or used to make a derivative work, by either mechanical, electronic or any other means in whole or in part, without prior written consent from DPS Telecom, except as required by United States copyright laws.

© 2015 DPS Telecom

### Notice

The material in this manual is for information purposes and is subject to change without notice. DPS Telecom shall not be liable for errors contained herein or consequential damages in connection with the furnishing, performance, or use of this manual.

# Contents

---

Visit our website at [www.dpstelecom.com](http://www.dpstelecom.com) for the latest PDF manual and FAQs

<b>1 CellVoice 4 /Trap Relay LT Overview</b>	<b>1</b>
<b>2 Setup</b>	<b>2</b>
<b>3 Specifications</b>	<b>9</b>
<b>4 Unit Back Panel</b>	<b>10</b>
4.1 Craft Port	10
4.2 LAN Connection	10
4.3 Integrated Temperature Sensor	10
4.4 D-Wire Sensor Inputs	11
<b>5 Unit Front Panel</b>	<b>12</b>
5.1 Discrete Alarms and Relay Connection	12
<b>6 Provisioning Menu Field Descriptions</b>	<b>14</b>
6.1 System	15
6.2 User Profiles	17
6.3 Ethernet	19
6.4 RADIUS	20
6.5 SNMP	21
6.6 Backup Mode	22
6.7 Phone List (CellVoice 4 only)	22
6.8 Notifications	23
6.8.1 How to Send Email Notifications	23
6.8.2 How to Send SNMP Traps	26
6.8.3 How to Send Voice Call Notifications (CellVoice 4 only)	28
6.8.4 How to Send SMS Notifications (CellVoice 4 only)	30
6.8.5 Notification Settings	31
6.8.6 Schedule	33
6.9 Alarms (If Available)	34
6.10 Controls (If Available)	35
6.11 Analogs (If Available)	36
6.12 Sensors	38
6.13 Ping Targets	40
6.14 Variable Bindings	41
6.15 SNMP Alarms	42
6.16 System Alarms	43
6.16.1 SMS Alarm (CellVoice 4 Only)	43
6.17 Timers	44
6.18 Date and Time	44

<b>7</b>	<b>Monitoring via the Web Browser</b>	<b>45</b>
7.1	Alarms (If Available)	45
7.2	Controls (If Available)	45
7.3	Analogs (If Available)	47
7.4	Sensors (If Available)	47
7.5	Ping Targets	48
7.6	SNMP Alarms	48
7.7	System Alarms	50
7.8	Alarm Log	51
<b>8</b>	<b>Device Access Descriptions</b>	<b>52</b>
<b>9</b>	<b>Reference Section</b>	<b>53</b>
9.1	Mounting Instructions	53
9.2	Firmware Upgrade	55
9.3	Front and Back Panel LED	56
9.4	Connecting to the unit via the Craft Port (using TTY Interface)	58
9.4.1	TTY Interface	66
9.4.2	Set DCP Parameters	66
9.5	Setting up Backup Mode	67
9.5.1	How to Setup Voice Call or SMS Notifications in Backup Mode Only (CellVoice 4 only)	68
9.6	Setting Up SMS for RRM (Rapid Response Monitoring)	70
9.7	Changing the Default Password	72
9.8	Analog Step Sizes	74
9.9	Display Mapping & System Alarms	74
9.10	Voice Notification Flow Chart (CellVoice 4 only)	80
9.11	SNMP Manager Functions	80
9.12	SNMP Granular Trap Packets	82
<b>10</b>	<b>Frequently Asked Questions</b>	<b>83</b>
10.1	General FAQs	83
10.2	SNMP FAQs	84
<b>11</b>	<b>Technical Support</b>	<b>85</b>
<b>12</b>	<b>End User License Agreement</b>	<b>88</b>

# 1 CellVoice 4 /Trap Relay LT Overview



## Effective, easy-to-install, light-capacity alarm monitoring

This unit is a compact, LAN-based, light-capacity remote telemetry unit. This unit is designed for easy installation at small and medium remote sites, making it cost-effective to deploy alarm monitoring throughout your entire telecom network. This unit features the monitoring capacity (plus voice dialing capabilities on the CellVoice 4) for flexible notifications.

## Powerful monitoring for smaller sites

This telco-grade remote is housed in a durable aluminum case that can be rack-mounted. This SNMP remote is scaled to the needs of small sites, such as remote huts, collocation racks, and enclosed cabinets - perfect for any site where a large capacity RTU would be more than you need.

- **4 Discrete Alarm Inputs**
- **1 Control Relay Outputs**
- **2 Analog Alarm Inputs (1 User Available & 1 Pre-set Power Monitoring)**
- **16 D-Wire temperature or humidity sensors**
- **32 Ping Targets**
- **32 SNMP Alarms**
- **Dial-in and out with DTMF acknowledge (CellVoice 4 only)**

## SNMP or T/Mon

The device can report alarms to any SNMP manager or to the DPS Telecom T/Mon Remote Alarm Monitoring System. The unit can also report via SNMP and DCPx concurrently to T/Mon.

## Easy Alerts via Email or SNMP

Email notification reports alarm events to the e-mail addresses of specified personnel and creates a supplemental record of alarm events in addition to your master via SNMP traps.

## Upgraded Web Browser

The overhauled web interface that boasts several new monitoring tools, including new analog gauges. You'll also notice the impressive speed boost. Menus load very quickly, and the alarm status updates automatically without requiring a page refresh.



*The unit can monitor other LAN devices at a site before LAN is available to the site.*

## 2 Setup

### Setup: Parts List

Please make sure all of the following items are included with your unit. If parts are missing, or if you ever need to order new parts, please refer to the part numbers listed and call DPS Telecom at **1-800-622-3314**.



**Resource Disk**



**Antenna**  
(CellVoice 4 only)



**Locking Power Connector**



**Ethernet Cable**



**USB Cable**



**Pads**



**Short Rack Ear**



**Wall Mount Bracket** x 2



**Wall Mount Screws** x 4



**Rack Screws** x 2



**Metric Rack Screws** x 2




**3/8" Ear Screws** x 4

## Setup: Powering the Device


**Note:** Always use safe power practices when making power connections. Make sure the power wires are **not active** before making any power connections.



To connect the unit to a power supply:



Battery lead left, and Ground right




FA LED Fuse left, power status LED , power plug right

- 1) Insert a battery *ground* wire into the connector's **right** terminal (Shown above) and battery *lead* into the **left** terminal and tighten the screws. Insert the connector into the power plug. Attach a grounding wire to the grounding lug .
- 2) Ensure the power status LED  is lit up green for correct polarity.
- 3) Insert the local fuse into the fuse holder.
- 4) The front panel status LED should flash RED and GREEN to indicate that the unit is operating.

## Setup: Connect via LAN

1) Connect PC and the unit to the same network via switch or directly via LAN cable.



- 2) Record your PC's current IP configuration (especially if static assignment).
- 3) Set your PC's IP address to **192.168.1.200** and subnet mask to **255.255.255.0** (Contact your IT department if you are unsure how to do this).
- 4) Browse to **192.168.1.100** (Compatible with IE8 or greater) on your PC and **log in** with default user: *admin* and password: *dpstelecom*.

<b>Username:</b>	<input type="text"/>
<b>Password:</b>	<input type="password"/>
<input type="button" value="Login"/>	

5) Provision the unit with the appropriate IP information for your network and restart the unit. Then restore your computer's IP configuration.

DPS Telecom

CellVoice 4

[Upload](#) | [Logout \(admin\)](#)

**Monitor**

Alarms

Controls

Analogs

Sensors

Ping Targets

SNMP Alarms

System Alarms

Alarm Log

**Provisioning**

System

User Profiles

**Ethernet**

RADIUS

SNMP

Backup Mode

Phone List

Notifications

Alarms

### Ethernet Settings


MAC Address		0:10:81:0:41:c0
Host Name	<input type="text"/>	( )
Enable DHCP	<input type="checkbox"/>	
Enable HTTP	<input checked="" type="checkbox"/>	
Unit IP	<input type="text" value="10.0.3.41"/>	(10.0.3.41)
Subnet Mask	<input type="text" value="255.255.0.0"/>	(255.255.0.0)
Gateway	<input type="text" value="10.0.0.254"/>	(10.0.0.254)
DNS Server 1	<input type="text" value="255.255.255.255"/>	(255.255.255.255)
DNS Server 2	<input type="text" value="255.255.255.255"/>	(255.255.255.255)

CellVoice Web Interface




## Setup: Configuring Cellular Modem (CellVoice 4 Only)

- 1) Attach the antenna to the device.




*The Antenna attaches to the CellVoice's back panel*

- 2) Locate the **Model #** and **ESN/IMEI** number from the sticker on the top of the unit and write them down for reference during cellular account setup and modem activation.
- 3) Contact Multi-Tech or your cellular provider to set up your account.
- 4) Go to [www.multitech.com](http://www.multitech.com) website and under the "Support" tab click on Cellular Modem Activation. Follow the instructions for activating your modem.
- 5) **If SIM card insertion is required** (GSM modem only):
  - a) Remove the power connector from the CellVoice unit.
  - b) Remove the 3 screws from the top cover of the CellVoice as shown below and remove the cover.



- c) Insert SIM card into the modem.



- d) Reattach cover and reinstall three screws.
- e) Insert the power connector into the CellVoice power plug.
- 6) **To establish terminal session to modem** (If necessary to program APN):
  - a) Telnet into the unit at port 2002 and log in with your username and password

```

CA. Telnet 10.0.3.41
CellVoice 4 Telnet Server
-ENT to login
-ESC to disconnect

Login: admin
Password: *****
Logged in successfully.

CellVoice 4 v1.0B.0008
DPS Telecom, Inc.

C>onfig P>ing ter(M)inal D>ebug e(X)it ? _

```

- b) Type 'M' to establish a terminal connection to the modem.
- c) Follow the instructions on the [www.multitech.com](http://www.multitech.com) website that are associated with your modem model and service provider to program the APN.

## Setup: Test Email Notification

1. Click on the **Notifications** button in the **Provisioning** menu. You can setup as many as 8 different notifications. Begin the setup "wizard" by clicking **Edit** for a notification number. In this example, we'll setup Notification 2 to send emails.

Notifications				
Summary				
Id	Notify On	Type	Details	
1	Disabled			<input type="button" value="Edit"/> <input type="button" value="Test"/>
2	Disabled			<input type="button" value="Edit"/> <input type="button" value="Test"/>
3	Disabled			<input type="button" value="Edit"/> <input type="button" value="Test"/>
4	Disabled			<input type="button" value="Edit"/> <input type="button" value="Test"/>
5	Disabled			<input type="button" value="Edit"/> <input type="button" value="Test"/>
6	Disabled			<input type="button" value="Edit"/> <input type="button" value="Test"/>
7	Disabled			<input type="button" value="Edit"/> <input type="button" value="Test"/>
8	Disabled			<input type="button" value="Edit"/> <input type="button" value="Test"/>

2. At the **Notification Setting** screen, use the drop down box to set what events to use for this notification. Now, select the **Send Email Notification** button and click **Save and Next**.

Notification 1	
Status	Notify on Alarms only <input type="button" value="v"/>
Type	<input checked="" type="radio"/> Send Email <input type="radio"/> Send SNMP <input type="radio"/> Voice Call <input type="radio"/> Send SMS
<input type="button" value="Back"/> <input type="button" value="Save and Next"/>	

3. At the **Email Notification** screen, you'll enter your email server settings. Enter the **IP address** or **Host Name** of your email server. Enter the **Port Number** (usually 25) and the **"To" Email Address** of the technician that will receive these emails. If authentication is required, chose the type and fill in the necessary fields. Click **Next**.

Notification 1 (Email)	
SMTP Server IP or Host Name	<input type="text"/>
Port (Usually Use 25)	<input type="text" value="0"/>
"From" E-mail Address (Global)	NGLT2@dpstete.net
"To" E-mail Address	<input type="text"/>
<b>How to authenticate</b>	
<input checked="" type="radio"/> No authentication <input type="radio"/> POP before SMTP authentication <input type="radio"/> SMTP authentication	
POP Server IP or Host Name	<input type="text"/>
POP Port (Usually Use 110)	<input type="text" value="0"/>
User name	<input type="text"/>
Password	<input type="text"/>
<input type="button" value="Back"/> <input type="button" value="Save and Next"/>	

4. At the **Schedule** screen accept default values.

Notification 1 (Schedule)

Id	Sun	Mon	Tue	Wed	Thu	Fri	Sat	Notification Time
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/> Any Time <input type="radio"/> 12 h 0 min AM to 11 h 59 min PM
2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/> Any Time <input type="radio"/> 12 h 0 min AM to 11 h 59 min PM

6. Use the test button to send yourself an email notification.

Notifications

Summary			
Id	Notify On	Type	Details
1	Both	Email	mailserver.net:25 / support@dpstele.net <input type="button" value="Edit"/> <input type="button" value="Test"/>
2	Disabled	Email	Server Not Configured <input type="button" value="Edit"/> <input type="button" value="Test"/>

**Congratulations!** Your notification settings are correct and your unit is live.


For more detailed configuration and setup, please reference the following sections:

- [6.8 Notifications](#)
- [6.9 Alarms](#)
- [6.10 Controls](#)
- [6.11 Analogs](#)
- [6.12 Sensors](#)
- [9.1 Mounting Instructions](#)

### 3 Specifications

<b>Discrete Alarm Inputs:</b>	Up to 4
<b>Analog Alarm Inputs:</b>	1 User Available 1 Power Monitoring (Optional)
<b>Analog Accuracy:</b>	+/- of Analog Range (See <b>Section 5.2, "Analog Step Sizes"</b> )
<b>Temperature Sensors:</b>	1 Integrated Sensor
<b>Temp. Thresholds:</b>	4
<b>Control Relay:</b>	1Form-C
<b>Max Carry Current:</b>	1A
<b>Max Operating Voltage:</b>	110VDC
<b>Max Operating Current:</b>	1A
<b>Max Switching Capacity:</b>	30W
<b>Ping Targets:</b>	32
<b>SNMP Alarms:</b>	32
<b>Sensor Inputs:</b>	Up to 16 D-Wire Sensors
<b>Protocols:</b>	SNMPv1, SNMPv2c, SNMPv3, DCPx, TELNET, HTTP, HTTPS
<b>Dimensions:</b>	1.720" H x 8.126" W x 7.146" D (4.369 cm x 20.641 cm x 18.152 cm)
<b>Weight:</b>	1 lb. 5 oz.
<b>Mounting:</b>	19" or 23" rack
<b>Power Input</b>	
<b>Voltage Options Include:</b>	Wide Range -24/-48VDC (-20 to -56 VDC) +24 VDC nominal via 110VAC wall transformer (20 to 36 VDC) -48VDC nominal (-36 to -72 VDC)
<b>Current Draw:</b>	100 mA @ 48VDC
<b>Fuse:</b>	1/2 Amp GMT Fuse if -48V or -24V
<b>Interfaces:</b>	1 RJ45 10/100BaseT full-duplex Ethernet port  1 USB rear-panel craft port Up to 4 Alarm input connectors (2 inputs per alarm) 1 Relay output connector (NO, NC, CO) 1 Push button switch (Optional) Internal Resettable Fuse if +12V or +24V (Optional) 1 RJ11 for D-Wire (Optional) 1 4-20 mA or 0-5V analog input (Optional) 1 12/24VDC Sensor power output up to 1/2A
<b>Visual Interface:</b>	9 Front Panel LEDs 6 Back Panel LEDs
<b>Operating Temperature:</b>	32°–140° F (0°–60° C)
<b>Operating Humidity:</b>	0%–95% non-condensing
<b>MTBF:</b>	60 years
<b>Windows Compatibility:</b>	Windows XP, 2000, Vista, 7 32/64 bit
<b>RoHS:</b>	5/6

## 4 Unit Back Panel




*CellVoice 4 back panel connections*

### 4.1 Craft Port

The back panel craft port is primarily used to give the unit an IP address so you can continue the rest of your database configuration over LAN.

### 4.2 LAN Connection



LAN is used for web browsing to the unit. You can also do your databasing over LAN, as well as sending email notifications and SNMP traps. To connect the unit to the LAN, insert a standard RJ45 Ethernet cable into the 10/100BaseT Ethernet port on the back of the unit. If the LAN connection is OK, the LNK LED will light **SOLID GREEN**.

### 4.3 Integrated Temperature Sensor

The unit features one internal temperature sensor, used to monitor the ambient temperature. The internal temperature sensor measures a range of -40° F to 180° F (-40° C to 82.2° C) within an accuracy of about  $\pm 2^\circ$ .

## 4.4 D-Wire Sensor Inputs

The ports on your unit labeled **Sensor Input** support up to 16 **D-Wire sensors**. Your unit powers and communicates with your D-Wire sensors via simple RJ-11 connections. You can chain your 16 sensors to the D-Wire port on the back of the unit in any order or combination.

The max cable length depends on the number of sensors daisy chained together. The cable lengths and corresponding number of sensors can be seen in the table below.


Maximum Cable Lengths							
Number of Nodes	Spec'd Max (ft)	Number of Nodes	Spec'd Max (ft)	Number of Nodes	Spec'd Max (ft)	Number of Nodes	Spec'd Max (ft)
1	800	9	150	17	75	25	50
2	700	10	125	18	75	26	50
3	475	11	125	19	50	27	50
4	350	12	100	20	50	28	50
5	275	13	100	21	50	29	50
6	225	14	100	22	50	30	40
7	200	15	75	23	50	31	40
8	175	16	75	24	50	32	40

*Maximum Cable Lengths*

**Note:** Some sensors may consume 2 analog channels (the combined temp/humidity sensor, D-PK-DSNSR-12002, for example).

### Connecting D-Wire Sensors

Using a **standard 6P4C, straight-through RJ-11 cable** (part #D-PR-045-10A-01, pinout below), connect any digital sensor port on the unit to the **In** jack on a D-Wire sensor. Chain additional sensors to the D-Wire sensor (using the same straight-through cables) from the **Out** jack on the previous sensor to the **In** jack on the next (i.e. Out on sensor 4 to In on sensor 5).




*Pinout for the unit and D-Wire Sensor RJ-11 jacks*

The D-Wire line of sensors includes temp/humidity, additional analogs, discretes, and more. Contact DPS at 1-800-693-0351 for information about available D-Wire sensors.

For details about configuring your sensors through the web interface, see the **Sensors** section of this manual.

## 5 Unit Front Panel

### 5.1 Discrete Alarms and Relay Connection



*Discrete alarm inputs, control relays, and the analog are wired using the spring-clamp terminal block connectors*


#### Latching Terminations

The unit features up to 4 discrete alarm inputs (depending on your build option). There are 2 input poles per alarm. The analog (depending on your build option) is intended for monitoring a single 4-20mA sensor. Your option may also include either 12 or 24VDC power output for power a sensor up to 1/2 AMP. The unit's relay connector has 3 outputs for Normally Open (NO), Normally Closed (NC), and Common (CO).


1. Strip a small piece off the end of the wire.
2. Flip open the connector for the desired alarm input. Lock it down over the wire.
3. Indicator LEDs on the front panel show you the summary status. Check for solid green light to see if power is connected.



### Dry Contact




### Contact to Ground



**Note:** Make sure that grounds have a common reference - this is usually done by tying grounds together.

### Form-C Contact



*Discrete alarm points can connect as a dry contact, a contact to ground, or a Form-C contact*

The discrete alarm inputs are also called digital inputs or contact closures. Discrete alarms are either activated or inactive, so they're typically used to monitor on/off conditions like power outages, equipment failures, door alarms and so on.

The unit's discrete alarm points are single-lead signals referenced to ground. The ground side of each alarm point is internally wired to ground, so alarm points can connect either as a dry contact or a contact to ground.

In a dry contact alarm, the alarm lead brings a contact to the ground lead, activating the alarm. In a contact to ground alarm, a single wire brings a contact to an external ground, activating the alarm.

## 6 Provisioning Menu Field Descriptions

The unit configuration is performed from the **Provisioning** menus (the menu options in green on the left-side of the web interface). The following pages provide a brief description of the options available in each menu.

### Saving Configuration Changes to the unit:

At the bottom of each screen you access from the **Provisioning** Menu, you will see a **Save** button. Clicking Save will cache your changes locally. The web interface will then prompt you to either **Write** your changes to the unit or **Reboot** the unit for changes to take effect in the top-left corner of your browser. The relevant options will be highlighted in the **Device Access** options.

**Note:** If the unit prompts you to both Write changes to the unit **and** Reboot, you will Write your changes first. Rebooting before without writing to the unit (if a Write is required) will cause you to lose your configuration changes.

Please **WRITE** to the unit after you are finished with your changes!  
Please **REBOOT** the unit for changes to take effect!

*Status messages on the unit Device Access menu, inform you how to implement your changes*

Device Access
Backup Config
Read
Write
Initialize
Get Log
Purge Log
Reboot

Device Access
Backup Config
Read
<b>Write (required)</b>
Initialize
Get Log
Purge Log
Reboot

*The control menu highlights items that must be completed for your changes to take effect*

## 6.1 System

From the **Provisioning > System** menu, you will configure and edit the global system, call, T/Mon and control settings for the unit.

System Settings	
<b>Global Settings</b>	
Name	CellVoice 4
Location	Fresno, CA
Contact/Account	559-454-1600
DTMF Pass Code	<input type="text"/> (Used when user first dials into the unit)
DTMF Record Pass Code	1234 (Used when user wants to record a description)
Rings Before Pickup	3
<b>SMS Send Limit Settings</b>	
SMS Send Limit	2
SMS Send Limit Period	5min (Time period before sent SMS counter is reset)
<b>DCP Responder Settings</b> <a href="#">Display Map</a>	
<input checked="" type="radio"/> Disable DCP <input type="radio"/> DCP over LAN	
DCP Unit ID / Protocol	1 / DCPx ▼
DCP over LAN port / Protocol	2001 / UDP ▼
<b>Analogs and Sensors History</b>	
Get history	<a href="#">history.csv</a>
Erase history	<input type="button" value="Erase"/>
<b>Voice Description Recording Options</b>	
Backup Description Recordings	<a href="#">CV4_voice.vc2</a>
Restore Description Recordings	<input type="button" value="Restore"/>
Erase Description Recordings	<input type="button" value="Erase"/>
<b>Unit Configuration</b>	
Backup Config	<a href="#">config.bin</a>
Initialize	<input type="button" value="Init"/>
<input type="button" value="Save"/>	

*The Provisioning > System menu*

<b>Global System Settings</b>	
<b>Name</b>	A name for this unit. (Optional field)
<b>Location</b>	The location of this unit. (Optional field)
<b>Contact</b>	Contact telephone number for the person responsible for this unit. (Optional field)
<b>DTMF Pass Code</b>	Used to login to the unit via telephone to hear alarm notifications. Only number entries are valid. <b>(CellVoice 4 only)</b>
<b>DTMF Record Pass Code</b>	Needed to access rights to record or re-record the custom (voice) alarm detail. Only number entries are valid. <b>(CellVoice 4 only)</b>
<b>Rings Before Pickup</b>	Used to change the number of rings before the unit picks up when dialing into it. <b>(CellVoice 4 only)</b>
<b>SMS Send Limit Settings</b>	
<b>SMS Send Limit</b>	Maximum SMS notifications that may be sent during the configured period. <b>Note:</b> This does not effect SMS re-broadcasts.
<b>SMS Send Limit Period</b>	Time period in which the unit retains the number of SMS notifications attempted to be sent.
<b>DCP Responder Settings (For use with T/Mon)</b>	
<b>DCP Unit ID / Protocol</b>	User-definable ID number for this unit (DCP Address) and desired protocol.
<b>DCP LAN</b>	Enter the DCP port for this unit (UDP/TCP port) and desired protocol.
<b>Analogs and Sensors History</b>	
<b>Get History</b>	Download a log of all configured analog and sensor values.
<b>Erase History</b>	Erase the log of all configured analog and sensor values.
<b>Voice Description Recording Options</b>	
<b>Backup Description Recordings</b>	Use this option to save your voice description recordings to your computer.
<b>Restore Description Recordings</b>	Use this option to upload your previously saved voice description recordings.
<b>Erase Description Recordings</b>	Use this option to erase all current voice description recordings.

## 6.2 User Profiles

Clicking **User Profiles** gives you access to modify the default username and password, and to edit the administrator profile and create up to 9 additional unique user profiles, each with different access rights to the unit's web interface.

User Profiles Summary			
Id	Username	Status	
1	admin	Default	<input type="button" value="Edit"/> (Administrator Profile)
2	tech1	Active	<input type="button" value="Edit"/> <input type="button" value="Delete"/>
3	after_hours_tech	Active	<input type="button" value="Edit"/> <input type="button" value="Delete"/>
4	tech2	Active	<input type="button" value="Edit"/> <input type="button" value="Delete"/>

*Configure access privileges for users in the User Profile screen*

**Note:** The first user profile in the User Profiles menu is the Administrator's Profile. Access rights for the administrator's profile are all enabled and may not be disabled, nor can the profile be deleted or suspended. This is a precaution to prevent a situation in which an access right is disabled for all users. You may still edit the **Username, Password, and Active Days** fields for the Administrator Profile.

User Profile 1 (Administrator Profile)	
<b>Suspend this Profile</b>	<input type="checkbox"/>
<b>Username</b>	admin
<b>Password</b>	••••••••
<b>Confirm Password</b>	••••••••
Access Rights	
<b>Check all</b>	<input type="checkbox"/>
<b>Edit logon profiles</b>	<input checked="" type="checkbox"/>
<b>Write config (change unit configuration)</b>	<input checked="" type="checkbox"/>
<b>View monitor pages</b>	<input checked="" type="checkbox"/>
<b>Send relay commands</b>	<input checked="" type="checkbox"/>
<b>TTY access (access via Craft port or via Telnet)</b>	<input checked="" type="checkbox"/>
<b>Initialize config to factory defaults</b>	<input checked="" type="checkbox"/>
<b>Upload new firmware, description recordings, or config</b>	<input checked="" type="checkbox"/>
<b>Get audit log</b>	<input checked="" type="checkbox"/>
<b>Purge (delete) audit log</b>	<input checked="" type="checkbox"/>
<b>Get (backup) config</b>	<input checked="" type="checkbox"/>
<b>Get and delete analog history</b>	<input checked="" type="checkbox"/>
<b>Get and delete description recordings</b>	<input checked="" type="checkbox"/>
<input type="button" value="Save"/>	
<a href="#">Go to profiles summary</a>	

*The User Profiles screen allows you control user functionality*

To create or edit any of the 10 user profiles (including the default), click the **Edit** button. From there, you can change all configurable settings for a user profile.

User Profile	
<b>Suspend this Profile</b>	If this box is checked, the profile will not be able to access the unit.
<b>Username</b>	Enter a username or a user description
<b>Password</b>	Enter a unique user password <b>Note:</b> All passwords are AES 128 encrypted.
<b>Confirm Password</b>	Re-enter the password.
Access Rights	
<b>Check all</b>	Enables all Access Rights
<b>Edit logon profiles</b>	Enables the user to add/modify user profiles and password information.
<b>Write Config (change unit configuration)</b>	Enables the user to change the unit config by accessing the <b>Write</b> feature in the control menu.
<b>View monitor pages</b>	Allows the user to access Monitor menu options.
<b>Send relay commands</b>	Allows the user to send commands to operate the device's control relays.
<b>TTY access (access via Craft port or via Telnet)</b>	Grants the user access to the unit via TTY interface (via craft or telnet).
<b>Initialize config to factory defaults</b>	Allows the user to use the <b>Initialize</b> option in the <b>Device Access</b> menu, resetting the unit to factory default settings. All user settings will be lost.
<b>Upload new firmware, description recordings, or config</b>	Allows the user to upload firmware or backed-up configuration files.
<b>Get audit log</b>	Allows the user to access the Audit Log ( <b>Get Log</b> command).
<b>Purge (delete) audit log</b>	Allows the user to delete the existing audit log.
<b>Get (backup) config</b>	Backs-up all user profile configuration settings.
<b>Get and delete analog history</b>	Allows the user to access and delete the analog and sensor history.
<b>Get and delete description recordings</b>	Allows the user to access and delete the recorded analog and sensor history.

*User profile field descriptions*

Once you've finished configuring a profile, click **Save** to store your changes locally.

To access another profile, simply click **Go to profiles summary** at the bottom of the page. You may also navigate away from the user profiles screen at any time by clicking any of the menu options on the left side of the screen.

## 6.3 Ethernet

The **Edit > Ethernet** menu allows you to define and configure Ethernet settings.

Ethernet Settings	
MAC Address	0:10:81:0:6f:19
Host Name	<input type="text"/> ( )
Enable DHCP	<input type="checkbox"/>
Unit IP	206.169.87.183 (206.169.87.183)
Subnet Mask	255.255.255.240 (255.255.255.240)
Gateway	206.169.87.177 (206.169.87.177)
DNS Server 1	8.8.8.8 (8.8.8.8)
DNS Server 2	4.4.4.4 (4.4.4.4)
<input type="button" value="Save"/>	

*The Provisioning > Ethernet menu*

Ethernet Settings	
<b>MAC Address</b>	Hardware address of the unit (Not editable - For reference only).
<b>Host Name</b>	Used only for web browsing. Example: If you don't want to remember this unit's IP address, you can type an alphanumeric name in this field, such as CV4. Once you save and reboot the unit, you can now browse to it locally by simply typing in "CV4" in the address bar (no "http://" needed).
<b>Enable DHCP</b>	Used to turn on Dynamic Host Connection Protocol. NOT recommended, because the unit is assigned an IP address from your DHCP server. The IP you've already assigned to the unit becomes inactive. Using DHCP means the unit will NOT operate in a T/Mon environment.
<b>Unit IP</b>	IP address of the unit.
<b>Subnet Mask</b>	A road sign to the unit, telling it whether your packets should stay on your local network or be forwarded somewhere else on a wide-area network.
<b>Gateway</b>	An important parameter if you are connected to a wide-area network. It tells the unit which machine is the gateway out of your local network. Set to 255.255.255.255 if not using. Contact your network administrator for this info.
<b>DNS Server 1</b>	Primary IP address of the domain name server. Set to 255.255.255.255 if not using.
<b>DNS Server 2</b>	Secondary IP address of the domain name server. Set to 255.255.255.255 if not using.

**Note:** DNS Server settings are required if a hostname is being used for ping targets.

## 6.4 RADIUS

RADIUS (Remote Authentication Dial In User Service) is an industry-standard way to manage logins to many different types of equipment in one central location. The unit connects to your central RADIUS server. Every time a device receives a login attempt (usually a username & password), it requests an authentication from the RADIUS server. If the username & password combination is found in the server's database, an affirmative "access granted" reply is sent back to the unit device, allowing the user to connect.

RADIUS	
<b>Global Settings</b>	
Retry	<input type="text" value="3"/>
Time-out	<input type="text" value="5sec"/>
<b>Server 1</b>	
IPA	<input type="text" value="255.255.255.255"/> (Disabled)
Port	<input type="text" value="1812"/>
Secret	<input type="text"/>
<b>Server 2</b>	
IPA	<input type="text" value="255.255.255.255"/> (Disabled)
Port	<input type="text" value="1812"/>
Secret	<input type="text"/>
<input type="button" value="Save"/>	

*The Provisioning > RADIUS menu*

RADIUS Settings	
<b>Retry</b>	Enter the number of times the RADIUS server should retry a logon attempt.
<b>Time-out</b>	Enter the number of seconds before a logon request is timed out.
Server 1/2	
<b>IPA</b>	Enter the IP address of the RADIUS server.
<b>Port</b>	Port 1812 is an industry-standard port for using RADIUS.
<b>Secret</b>	Enter the RADIUS secret in this field.

After successfully entering the settings for the RADIUS server, the unit Web Browser will prompt users for both a Username and Password, which will be verified using the information and access rights stored in the RADIUS database.

RADIUS logins are **case-sensitive**. If the RADIUS server is unavailable or access is denied, the local user profiles will work via craft port access only. Also, the "dictionary.dps" files (included on the Resource Disk) needs to be loaded on the RADIUS server for access-right definition. If RADIUS is enabled on the unit, local authentication will be invalid through the web and can only work via craft port.



## 6.5 SNMP

The **Provisioning > SNMP** menu allows you to define and configure the SNMP settings.

**SNMP**

**Global Settings**

<b>Get Community</b>	<input type="text" value="dps_public"/>
<b>Set Community</b>	<input type="text" value="dps_public"/>
<b>Trap Community</b>	<input type="text" value="dps_public"/>
<b>Trap Listening Port</b>	<input type="text" value="162"/>
<b>Read and Write Access</b>	<input type="text" value="SNMPv3, SNMPv2c, and SNMPv1"/>
<b>SNMPv3 Engine ID</b>	<input type="text" value="80000a7a0300108100697a"/>

**SNMPv3 Users**

Id	SNMPv3 Username	Auth Type	Auth Pass	Priv Type	Priv Pass
1	<input type="text"/>	No Auth	<input type="text"/>	No Priv	<input type="text"/>
2	<input type="text"/>	No Auth	<input type="text"/>	No Priv	<input type="text"/>
3	<input type="text"/>	No Auth	<input type="text"/>	No Priv	<input type="text"/>

*The Provisioning > SNMP menu*

Global Settings	
<b>Get Community</b>	Community name for SNMP requests.
<b>Set Community</b>	Community name for SNMP SET requests.
<b>Trap Listening Port</b>	The port through which traps are listened for or received. By default, the trap listening port is 162.
<b>Read and Write Access</b>	This field defines how the unit may be accessed via SNMP. This can be set to the following: <ul style="list-style-type: none"> <li>• <b>SNMP v2c and SNMP v1-only:</b> Allows SNMPv1 and SNMPv2c access <b>(Default)</b></li> <li>• <b>SNMP v2c only:</b> Allows SNMPv2c access only</li> <li>• <b>Access Disabled:</b> Restricts all access to unit via SNMP</li> </ul>
<b>SNMPv3 Engine ID</b>	The engine identification that uniquely identifies the agent in the device.
SNMPv3 Users	
<b>Username</b>	Community name for SNMP requests.
<b>Auth Type</b>	Select the authentication type.
<b>Auth Pass</b>	Specify the authentication password.
<b>Priv Type</b>	Select the privacy type.
<b>Priv Pass</b>	Specify the privacy password.

## 6.6 Backup Mode

The **Provisioning > Backup Mode** menu allows you to define and configure Backup Mode alarms. The Backup Mode menu provides a list of preset alarms, as well as the ability to create user defined alarms from the Display Map. You can also create wireless Backup Mode notifications using Voice and SMS (CellVoice 4 only). For more information, see **Section 10.5** "Setting up Backup Mode."

Backup Settings	
DCP Fail	<input checked="" type="checkbox"/>
SNMP Fail	<input type="checkbox"/>
Notification 1	<input type="checkbox"/>
Notification 2	<input checked="" type="checkbox"/>
Notification 3	<input checked="" type="checkbox"/>
Notification 4	<input checked="" type="checkbox"/>
Notification 5	<input type="checkbox"/>
Notification 6	<input type="checkbox"/>
Notification 7	<input checked="" type="checkbox"/>
Notification 8	<input type="checkbox"/>
User Defined - Display: <input type="text" value="1"/> Point: <input type="text" value="1"/> <a href="#">Display Map</a>	<input type="checkbox"/>

*The Provisioning > Backup Mode menu.*

## 6.7 Phone List (CellVoice 4 only)

Up to 32 phone numbers can be stored for the CellVoice 4 to call with alarm information. This list is unordered and should include all phone numbers for those that need to know and/or respond to alarms. When setting up a voice call notification later, you can designate which of these individuals to call about which alarms, in your desired order.

Slot	Enab	Msg Type	Description	Phone Number
1	<input checked="" type="checkbox"/>	Voice Call	Tech1	559-454-1600
2	<input checked="" type="checkbox"/>	SMS	Tech2	800-622-3314
3	<input checked="" type="checkbox"/>	SMS-Mon	Tech3	800-693-0351

*The Provisioning > Phone List menu*

Phone List Settings	
<b>Message Type</b>	Description.
<b>Voice Call</b>	Recipient will receive a phone call with notification of event.
<b>SMS</b>	Recipient will receive a SMS message in standard format.
<b>SMS-Mon</b>	Recipient will receive a SMS message in RRM (Rapid Response Monitoring) format.

## 6.8 Notifications

From the initial **Provisioning > Notifications** menu, you will see which of the 8 notifications are enabled, their type, and details. Click on the **Edit** link for one of the notifications to begin configuration.

Once you've chosen which notification you want to setup, click the **Edit** button on the right-hand side to begin configuration. Then choose a notification method: Email, SNMP, Voice Call, or SMS (voice call and SMS available on CellVoice 4 only). Now click **Save and Next** to continue to a Notification Settings screen.

### 6.8.1 How to Send Email Notifications

1. Click on the **Notifications** button in the **Provisioning** menu. You can setup as many as 8 different notifications. Begin the setup "wizard" by clicking **Edit** for a notification number. In this example, we'll setup Notification 2 to send emails.

Notifications				
Summary				
Id	Notify On	Type	Details	
1	Disabled			<a href="#">Edit</a> <a href="#">Test</a>
2	Disabled			<a href="#">Edit</a> <a href="#">Test</a>
3	Disabled			<a href="#">Edit</a> <a href="#">Test</a>
4	Disabled			<a href="#">Edit</a> <a href="#">Test</a>
5	Disabled			<a href="#">Edit</a> <a href="#">Test</a>
6	Disabled			<a href="#">Edit</a> <a href="#">Test</a>
7	Disabled			<a href="#">Edit</a> <a href="#">Test</a>
8	Disabled			<a href="#">Edit</a> <a href="#">Test</a>

2. At the **Notification Setting** screen, use the drop down box to set what events to use for this notification. Now, select the **Send Email Notification** button and click **Save and Next**.

Notification 1	
<b>Status</b>	Notify on Alarms only <input type="text"/>
<b>Type</b>	<input checked="" type="radio"/> Send Email <input type="radio"/> Send SNMP <input type="radio"/> Voice Call <input type="radio"/> Send SMS
<input type="button" value="Back"/> <input type="button" value="Save and Next"/>	

3. At the **Email Notification** screen, you'll enter your email server settings. Enter the **IP address** or **Host Name** of your email server. Enter the **Port Number** (usually 25) and the **"To" Email Address** of the technician that will receive these emails. If authentication is required, chose the type and fill in the necessary fields. Click **Next**.

**Notification 1 (Email)**

SMTP Server IP or Host Name	<input type="text"/>
Port (Usually Use 25)	<input type="text" value="0"/>
"From" E-mail Address (Global)	<input type="text" value="NGLT2@dpstela.net"/>
"To" E-mail Address	<input type="text"/>
<b>How to authenticate</b>	
<input checked="" type="radio"/> No authentication <input type="radio"/> POP before SMTP authentication <input type="radio"/> SMTP authentication	
POP Server IP or Host Name	<input type="text"/>
POP Port (Usually Use 110)	<input type="text" value="0"/>
User name	<input type="text"/>
Password	<input type="password"/>
<input type="button" value="Back"/> <input type="button" value="Save and Next"/>	

4. At the **Schedule** screen, you'll select the exact days/times you want to receive email notifications. You can set 2 schedules per notification. For example, you may want to receive notifications at certain times during the week, and at different hours on the weekend. Use the check boxes to select the days of the week, and select the time from the drop down menus. Click **Finish**. To try a test notification, click the **Test** button (See next step.)

**Notification 1 (Schedule)**

Id	Sun	Mon	Tue	Wed	Thu	Fri	Sat	Notification Time
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/> Any Time <input checked="" type="radio"/> 12 h 0 min AM to 11 h 59 min PM
2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/> Any Time <input checked="" type="radio"/> 12 h 0 min AM to 11 h 59 min PM

5. If you chose to test the email notification you've just setup, you will prompted with a pop up . Click **OK** to send a test email alarm notification. Confirm all your settings by checking your email to see if you've received it. **NOTE:** This test only means that your notification settings are correct, but you still need to assign the notification to an alarm point. See the next step.

6. Now you will associate this notification to an alarm (system, base, analog, etc.) You have 8 notification devices available to use. In the image below, you might assign **Notification Device 1** to **Alarm 1**. This means that you would receive an email notification when an alarm for **Alarm 1** (SERVER ROOM) occurs.

**DPS Telecom**  
Network Monitoring Solutions Upload | Logout (admin)

**Monitor**  
Alarms  
Controls  
Analog  
Sensors  
System Alarms  
Provisioning  
System  
User Profiles  
Ethernet  
SNMP  
Phone List  
Notifications  
Alarms  
Controls  
Analog

### Notifications

**Summary**

Id	Notify On	Type	Details
1	Disabled		<input type="button" value="Edit"/> <input type="button" value="Test"/>
	Disabled		<input type="button" value="Edit"/> <input type="button" value="Test"/>
	Disabled		<input type="button" value="Edit"/> <input type="button" value="Test"/>
	Disabled		<input type="button" value="Edit"/> <input type="button" value="Test"/>
	Disabled		<input type="button" value="Edit"/> <input type="button" value="Test"/>
	Disabled		<input type="button" value="Edit"/> <input type="button" value="Test"/>
	Disabled		<input type="button" value="Edit"/> <input type="button" value="Test"/>
	Disabled		<input type="button" value="Edit"/> <input type="button" value="Test"/>

**DPS Telecom**  
Network Monitoring Solution Upload | Logout (admin)

**Monitor**  
Alarms  
Controls  
Analog  
Sensors  
System Alarms  
Provisioning  
System  
User Profiles  
Ethernet  
SNMP  
Phone List  
Notifications  
Alarms  
Controls  
Analog

### Alarms

Id	Description	Display Map	Rev.	1	2	3	4	5	6	7	8
1	SERVER ROOM	<input type="text" value="Advanced&lt;&lt;"/>		<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
2	WEST SIDE DOOR	<input type="text" value="Advanced&gt;&gt;"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	RECTIFIER	<input type="text" value="Advanced&gt;&gt;"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	MICROWAVE	<input type="text" value="Advanced&gt;&gt;"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

On Set:   
On Clear:   
Qual. Time:   
Qual. Type:

## 6.8.2 How to Send SNMP Traps

1. Click on the **SNMP** button in the **Provisioning** menu. Enter the **SNMP GET** and **SNMP SET** community strings for your network, then click **Save**. The typical SNMP SET and GET community strings for network devices is "public". As an added security measure, we've made our default "dps\_public".

**SNMP**

**Global Settings**

Get Community	dps_public
Set Community	dps_public
Trap Community	dps_public
Trap Listening Port	162
Read and Write Access	SNMPv3, SNMPv2c, and SNMPv1
SNMPv3 Engine ID	80000a7a0300108100697a

**SNMPv3 Users**

Id	SNMPv3 Username	Auth Type	Auth Pass	Priv Type	Priv Pass
1		No Auth		No Priv	
2		No Auth		No Priv	
3		No Auth		No Priv	

Save

2. Click on the **Notifications** button in the **Provisioning** menu. You can setup as many as 8 different notifications. Begin the setup "wizard" by clicking **Edit** for a notification number. In this example, we'll setup Notification 1 to send SNMP traps to your alarm master.

**Notifications**

**Summary**

Id	Notify On	Type	Details	
1	Both	SNMP	10.0.6.5:1234	Edit Test
2	Disabled	Email	10.0.6.5:1234 / CellV4@dpstele.net	Edit Test
3	Disabled	Voice Call	See phone list.	Edit Test
4	Disabled	Voice Call	See phone list.	Edit Test
5	Disabled	Voice Call	See phone list.	Edit Test
6	Disabled	Voice Call	See phone list.	Edit Test
7	Disabled	Voice Call	See phone list.	Edit Test
8	Disabled	SMS	5555555555	Edit Test

3. At the **Notification Setting** screen, use the drop down box to set which events to use for this notification. Now, select the **Send SNMP Notification** button and click Next.

**Notification 1**

Status: Notify on Alarms only

Type:

- Send Email
- Send SNMP
- Voice Call
- TRIP Dialup (T/Mon)

4. At the **SNMP Notification** screen, you'll enter your network's SNMP settings. Enter the **IP address** of your SNMP Trap Server. Enter the **Trap Port Number** (usually 162) and the **Trap Community** password. Click **Save**

and Next.

Notification 4 (SNMP)

SNMP Trap Server IP	<input type="text"/>
Trap Port No. (Usually Use 162)	<input type="text" value="0"/>
Trap Community	<input type="text"/>
Trap Type	SNMPv3 <input type="button" value="v"/>
SNMPv3 user (see SNMP menu)	User 1 ( ) <input type="button" value="v"/>
<input type="button" value="Back"/> <input type="button" value="Save and Next"/>	

5. At the **Schedule** screen, you'll select the exact days/times you want to receive SNMP notifications. You can set 2 schedules per notification. For example, you may want to receive notifications at certain times during the week, and at different hours on the weekend. Use the check boxes to select the days of the week, and select the time from the drop down menus. Click **Save and Finish**. To try a test notification, click the **Test** button (See next step.)

Notification 1 (Schedule)

Id	Sun	Mon	Tue	Wed	Thu	Fri	Sat	Notification Time
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/> Any Time <input type="radio"/> 12 h 0 min AM to 11 h 59 min PM
2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/> Any Time <input type="radio"/> 12 h 0 min AM to 11 h 59 min PM
<input type="button" value="Back"/> <input type="button" value="Save and Finish"/>								

6. If you chose to test the email notification you've just setup, you will prompted with a pop up . Click **OK** to send a test SNMP alarm notification. Confirm all your settings by checking your alarm master to see if the SNMP trap was received.

**NOTE:** This test only means that your notification settings are correct, but you still need to assign the notification to an alarm point. See Step 6 in "How to Send Email Notifications" for more detail.

### 6.8.3 How to Send Voice Call Notifications (CellVoice 4 only)

The following instructions will guide you through the process of setting up the unit to call your phone when alarms are triggered. Using your custom call list, the CellVoice 4 will begin the calling tree to notify the correct personnel, according to their schedules.

1. Click on the **Notifications** button in the **Provisioning** menu. You can setup as many as 8 different notifications. Begin the setup "wizard" by clicking on **Edit** for a notification number. In this example, we'll setup Notification 6 to send an voice alert.
2. At the **Notification Setting** screen, select the conditions you want to be notified of from the drop down: **Notify on both Alarms and Clears, Notify on Alarms only, Notify on Clears only**. (Selecting Notification Disabled means you will not receive any type of alerts.) Select **Voice Call** and click **Save and Next**.

**Notification 1**

Status: Notification Disabled

Type:
 

- Send Email
- Send SNMP
- Voice Call
- Send SMS

Back Save and Next

3. At the next screen, you'll select the phone numbers the CellVoice should call when the alarm that corresponds to this particular notification is triggered. Make your selections, in order, using the drop down lists. These are the phone numbers you entered in the **Provisioning > Phone List** menu. To jump to this menu and add more numbers, click the **Add Phones** link in the title bar. In the **Delay** field, enter the amount of time that should pass before the CellVoice attempts to call the next person on the phone tree. (s = seconds; m = minutes)

**Notification 1 (Voice Call)**

Id	Phone Number to Call (Add Phone Numbers)	Delay
1	Phone List slot 1 has no number!	1s
2	Phone List slot 2 has no number!	1min
3	Phone List slot 3 has no number!	5min
4	Phone List slot 3 has no number!	25min

Call all numbers in this list. Ack logic is disabled.  
 Extend Call Loop. Unit will loop through call list 5 times. The loop ends when call is acked. If ack never occurs, the notification failed alarm is set and the loop ends.  
 Send notification only if in Backup Mode.

Back Save and Next

**NOTE:** At the bottom of this screen, you may choose the **"Call all numbers"** box to disable acking. When checked, the unit will call all numbers in the list, instead of stopping when the alarm or clear is acknowledged. You may also choose to choose whether you want the CellVoice to dial ONLY if a **Backup Mode** Point is set. See **Section 9.5** for more information.

5. At the **Schedule** screen, you'll select the exact days/times you want to receive notifications. You can set 2 schedules per notification. For example, you may want to send after hours or at certain times during the week, and



at different hours on the weekend. Use the check boxes to select the days of the week, and select the time from the drop down menus. Click **Save and Finish**. To try a test notification, click the **Test** button (See next step.)

Notification 1 (Schedule)

Notification 1 (Schedule)								
Id	Sun	Mon	Tue	Wed	Thu	Fri	Sat	Notification Time
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/> Any Time <input type="radio"/> 12 h 0 min AM to 11 h 59 min PM
2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/> Any Time <input type="radio"/> 12 h 0 min AM to 11 h 59 min PM

6. If you chose to test the notification, you will see the popup below. Click **OK** to test a voice notification. **NOTE:** This test only means that your notification settings are correct, but you still need to assign the notification to an alarm point.

7. Now you will associate this notification to an alarm (system, base, analog, etc.) You have 8 notification devices available to use. In the image below, you might assign **Notification Device 1** to **Alarm 1**. This means that you would receive an email notification when an alarm for SERVER ROOM occurs. Remember that Notification #1 in the Notifications menu is the same as N1 on the alarms page.

The screenshot shows the DPS Telecom Network Monitoring Solutions interface. On the left is a navigation menu with categories: Monitor, Alarms, Controls, Analogs, Sensors, System Alarms, Provisioning, System, User Profiles, Ethernet, SNMP, Phone List, Notifications, Alarms, Controls, and Analogs. The main content area is split into two sections: 'Notifications' and 'Alarms'. The 'Notifications' section has a 'Summary' table with columns 'Id', 'Notify On', 'Type', and 'Details'. It lists 8 notifications, all with 'Notify On' set to 'Disabled'. A red circle highlights the first row (Id 1). The 'Alarms' section has a table with columns 'Id', 'Description', 'Display Map', 'Rev.', and 8 columns for notification devices (1-8). The first row (Id 1) is 'SERVER ROOM' with 'Rev.' 1. A red circle highlights the '1' in the 'Display Map' column. Below the table are settings for 'On Set', 'On Clear', 'Qual. Time', and 'Qual. Type'. A red line connects the red circle in the Notifications table to the red circle in the Alarms table, indicating the association between Notification Device 1 and Alarm 1.

## 6.8.4 How to Send SMS Notifications (CellVoice 4 only)

1. Click on the **Notifications** button in the **Provisioning** menu. You can setup as many as 8 different notifications. Begin the setup "wizard" by clicking on **Edit** for a notification number. In this example, we'll setup Notification 8 to send an SMS notification.

2. At the **Notification Setting** screen, select the conditions you want to be notified of from the drop down: **Notify on both Alarms and Clears**, **Notify on Alarms only**, **Notify on Clears only**. (Selecting Notification Disabled means you will not receive any type of alerts.) Select **Send SMS** and click Save and Next.

Notification 1

<b>Status</b>	Notify on both Alarms and Clears ▼
<b>Type</b>	<input type="radio"/> Send Email <input type="radio"/> Send SNMP <input type="radio"/> Voice Call <input checked="" type="radio"/> Send SMS
<input type="button" value="Back"/> <input type="button" value="Save and Next"/>	

3. At the next screen, you'll enter the phone number or email address that the CellVoice should send a message to when the alarm that corresponds to this notification is triggered. Enter the phone number or email address, select an email gateway if necessary, and choose whether you want the CellVoice to dial **ONLY** if a Backup Mode Point is set. Then click **Save and Next**.

**Note:** When sending an SMS, you can either use hyphens to separate phone numbers or type the entire number in without hyphens (555-555-5555 or 5555555555). However, if you are sending an SMS using the **Email Gateway**, you must remove all dashes. **Example:** 555-555-5555 becomes 5555555555@txt.att.net

Notification 1 (SMS)

<b>Phone Number or Email Address</b>	555-555-5555
<b>Email Gateway</b>	None ▼ <b>This is required for SMS-to-Email</b>
<b>Backup Mode</b>	<input type="checkbox"/> Send notification only if in Backup Mode.
<input type="button" value="Back"/> <input type="button" value="Save and Next"/>	

5. At the **Schedule** screen, you'll select the exact days/times you want to receive notifications. You can set 2 schedules per notification. For example, you may want to send after hours or at certain times during the week, and at different hours on the weekend. Use the check boxes to select the days of the week, and select the time from the drop down menus. Click **Save and Finish**. To try a test notification, click the **Test** button (See next step.)

Notification 1 (Schedule)

Id	Sun	Mon	Tue	Wed	Thu	Fri	Sat	Notification Time
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/> Any Time 12 h 0 min AM to 11 h 59 min PM
2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/> Any Time 12 h 0 min AM to 11 h 59 min PM
<input type="button" value="Back"/> <input type="button" value="Save and Finish"/>								

6. Click **Test** to send a test SMS notification. **NOTE:** This test only means that your notification settings are correct, but you still need to assign the notification to an alarm point (See step 6 of the "How to Send Email Notifications" section).

## 6.8.5 Notification Settings

### Email Notification Fields

#### Notification 1 (Email)

<b>SMTP Server IP or Host Name</b>	email@dpstele.net
<b>Port (Usually Use 25)</b>	25
<b>"From" E-mail Address (Global)</b>	CellIV@dpstele.net
<b>"To" E-mail Address</b>	noc@dpstele.net
<b>How to authenticate</b>	
<input checked="" type="radio"/> No authentication <input type="radio"/> POP before SMTP authentication <input type="radio"/> SMTP authentication	
<b>POP Server IP or Host Name</b>	
<b>POP Port (Usually Use 110)</b>	0
<b>User name</b>	
<b>Password</b>	
<input type="button" value="Back"/> <input type="button" value="Save and Next"/>	

#### *Editing Email Notification Settings*

Email Notification	
<b>SMTP Server IP or Host Name</b>	The IP address of your email server.
<b>Port Number</b>	The port used by your email server to receive emails, usually set to 25.
<b>"From" E-mail Address</b>	Displays the email address (defined in the Edit menu > System) that the unit will send emails from. Not editable from this screen.
<b>"To" E-mail Address</b>	The email address of the person responsible for this unit, who will receive email alarm notifications.

**Note:** If you want to send authenticated emails, click the appropriate radio button. If you enable POP authentication, you will have to enter the relevant authentication information the fields below.

## SNMP Notification Fields

### Notification 1 (SNMP)

<b>SNMP Trap Server IP</b>	<input type="text" value="10.0.6.5"/>
<b>Trap Port No. (Usually Use 162)</b>	<input type="text" value="1234"/>
<b>Trap Community</b>	<input type="text"/>
<b>Trap Type</b>	<input type="text" value="SNMPv1"/>
<b>SNMPv3 user (see SNMP menu)</b>	<input type="text" value="User 1 ()"/>
<input type="button" value="Back"/> <input type="button" value="Save and Next"/>	

*Editing SNMP notification settings*

SNMP Notification	
<b>SNMP Trap Server IP</b>	The SNMP trap manager's IP address.
<b>Trap Port No.</b>	The SNMP port (UDP port) set by the SNMP trap manager to receive traps, usually set to 162.
<b>Trap Community</b>	Community name for SNMP TRAP requests.
<b>Trap Type</b>	Indicate whether you would like to send SNMP v1, v2c, or v3 traps.

## Voice Call Notification Fields (CellVoice 4 only)

### Notification 1 (Voice Call)

Notification 1 (Voice Call)		
Id	Phone Number to Call (Add Phone Numbers)	Delay
1	<input type="text" value="Phone List slot 1 has no number!"/>	<input type="text" value="1s"/>
2	<input type="text" value="Phone List slot 2 has no number!"/>	<input type="text" value="1min"/>
3	<input type="text" value="Phone List slot 3 has no number!"/>	<input type="text" value="5min"/>
4	<input type="text" value="Phone List slot 3 has no number!"/>	<input type="text" value="25min"/>

*Editing voice call notification settings*

Voice Call Notification	
<b>Phone number to call</b>	Phone number the CellVoice will call with incoming alarm information.
<b>Delay</b>	The amount of time that will pass before the CellVoice will call the next person on the assigned call list. Enter s for seconds or m for minutes. <i>Example: 45s = 45 seconds.</i>
<b>Call all numbers in this list. Ack logic is disabled.</b>	Forces the CellVoice to call everyone on the assigned call list, disabling their ability to ack the alarm and stop the phone tree process.
<b>Extended call loop.</b>	If checked, all configured phone numbers will be dialed (in the order entered) five times or until the alarm is acknowledged.

## SMS Notification Fields (CellVoice 4 only)

**Notification 1 (SMS)**

<b>Phone Number or Email Address</b>	555-555-5555
<b>Email Gateway</b>	None <input type="button" value="v"/> <b>This is required for SMS-to-Email</b>
<b>Backup Mode</b>	<input type="checkbox"/> <b>Send notification only if in Backup Mode.</b>

*Editing Call notification settings*

Call Notification	
<b>Phone Number or Email Address</b>	Enter the phone number or email address that will receive the SMS.
<b>Email Gateway</b>	The Email Gateway should match your CellVoice's carrier.
<b>Backup Mode</b>	Check this box if you want the CellVoice to only dial if in Backup Mode.

**Note:** If you are going cross-carrier (eg. Verizon to ATT), you will need to select Verizon for the Email Gateway and use an ATT domain in the email address (e.g. phonenumber@txt.att.net).

## 6.8.6 Schedule

The notifications scheduling menu is where you will tell the unit exactly which days and times you want to receive alarm notifications. You set 2 different schedules for each.

**Notification 1 (Schedule)**

Id	Sun	Mon	Tue	Wed	Thu	Fri	Sat	Notification Time
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/> <b>Any Time</b> <input type="radio"/> 12 h 0 min AM to 11 h 59 min PM
2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="radio"/> <b>Any Time</b> <input type="radio"/> 12 h 0 min AM to 11 h 59 min PM

*The Schedule creation screen*

Notification Scheduling	
<b>Days of the week</b>	From either Schedule 1 or 2, check which days you want to receive notifications.
<b>Any Time</b>	Select this is if you want to receive alarm notifications at any time for the day(s) you've selected.
<b>Notification Time</b>	Tells the unit to only send notifications during certain hours on the day(s) you've selected.

## 6.9 Alarms (If Available)

Discrete alarms are configured from the **Provisioning > Alarms** menu. Descriptions for the alarm points, polarity (normal or reversed) and notification type(s) are defined from this menu. You also have the option to use **Basic** or **Advanced** configuration methods, explained in this section.

The screenshot shows the 'Alarms' configuration interface. It features a table with columns for 'Id', 'Description', 'Display Map', and 'Rev.' (1-8). The first row is expanded to show configuration options for 'Front Door':

- On Set: Alarm
- On Clear: Clear
- Qual. Time: 30sec
- Qual. Type: OnSet
- Severity: None

Other rows include 'Tower Lights', 'Commercial Power', and 'Router 1', each with an 'Advanced' link. A 'Save' button is at the bottom.

The Provisioning > Alarms menu

Basic Alarm Configuration	
<b>ID</b>	Alarm ID number.
<b>Description</b>	User-definable description for the discrete alarm point.
<b>Rev (Reverse)</b>	Reverse: Check this box to reverse the polarity of the alarm point. Leaving this option un-checked means a normally open contact closure is an alarm. When polarity is reversed, a normally closed alarm point is clear when closed.
<b>Notification Devices</b>	Check which notification device(s), 1 through 8, will send alarm notifications in response to this alarm point.
Advanced Alarm Configuration (Advanced>>)	
<b>On Set</b>	User-definable description (condition) that will appear for the discrete alarm input on Set. Example: "Alarm".
<b>On Clear</b>	User-definable description (condition) that will appear for the discrete alarm input on Clear: "Example: "Alarm Cleared".
<b>Qual. Time (Qualification Time)</b>	The length of time that must pass, without interruption, in order for the condition to be considered an Alarm or a Clear.
<b>Qual. Type (Qualification Type)</b>	Allows you to choose whether you want to apply the Qualification Time to the alarm Set, Clear, or Both.
<b>Severity</b>	Allows you to choose the severity of the alarm. Primarily used to display the alarm type when using the "SMS-Mon" notification format for RRM (Rapid Response Monitoring).

## 6.10 Controls (If Available)

The unit's control relays can be configured in the **Provisioning > Controls** menu. You can enter your own description for these relays and designate them to a notification device(s).

*The Provisioning > Controls screen*

Basic Controls Configuration	
<b>ID</b>	ID number for the control relay.
<b>Description</b>	User-definable description for the unit's control relay.
<b>Momentary Time</b>	Control on time (in milliseconds) when you execute the MOM command. Max limit of 600 seconds.
<b>Notification Devices</b>	Check which notification device(s), 1 through 8, you want to send alarm notifications for the control relay.
<b>Derived Description</b>	Control relays and virtual alarms can be created with a derived formula. See below for more information.

### Derived Description Coding

**\_OR** : Set the current operation to OR.  
**\_AN** : Set the current operation to AND.  
**\_XR** : Set the current operation to XOR.  
**D** : Tag to change the active display number.  
**G** : Tag to change the active group number.  
**.** : Used like a comma to delimit numbers.  
**-** : Used to specify a range of points.

### Examples:



Spaces included in the bolded code below are for readability purposes only.

**\_OR D1.3-5** is logically equivalent to (1.3 || 1.4 || 1.5)  
**\_AN D 1.3-5 D2.6 \_OR D3.7** is logically equivalent to ((1.3 && 1.4 && 1.5 && 2.6) || 3.7)  
**\_OR D01.03-05 D02.06 \_AN D02.07 D03.10.-12** is logically equivalent to ((1.3 || 1.4 || 1.5 || 2.6&& (2.7 && 3.10 && 3.12))  
**\_AN D1.3-5D2.6 \_OR.7D3.10.12** is logically equivalent to ((1.3 && 1.4 && 1.5 && 2.6) || 2.7 || 3.10 || 3.12))  
**o** will not parse  
**\_AN D1-2** : Control will parse  
**\_OR G1** will latch if any alarm in group 1 is active



## 6.11 Analogs (If Available)

The unit can have up to 2 analog channels. The 1st channel is pre-configured for power monitoring. The 2nd channel is a user-definable analog that supports 0-5V or 5-20mA. Both of these channels support the entire range of power inputs that the units can support. Each channel must be individually configured to monitor data.

**Note:** Only analogs supported by the units hardware will appear in the unit web browser interface.

**User Analogs**


Id	Enab	Description	<a href="#">Display Map</a>	1	2	3	4	5	6	7	8
2	<input checked="" type="checkbox"/>	Room Temperature	<a href="#">Details&lt;&lt;</a>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Record Freq: <input type="text" value="5min"/> Deadband: <input type="text" value="1"/> On Set: <input type="text" value="Alarm"/> On Clear: <input type="text" value="Clear"/> Qual. Time: <input type="text" value="0sec"/> Qual. Type: <input type="text" value="OnSet"/>	Scaling: <input type="text" value="Actual"/> to <input type="text" value="Display"/> Units: <input type="text" value="VDC"/> to <input type="text" value="mA"/> Low ref: <input type="text" value="-35"/> to <input type="text" value="-35"/> High ref: <input type="text" value="35"/> to <input type="text" value="35"/>	Thresholds: MjU: <input type="text" value="-79.00"/> MnU: <input type="text" value="-35.00"/> MnO: <input type="text" value="35.00"/> MjO: <input type="text" value="79.00"/>
---	--	---


**Analog Gauge Type:**

None









*The Provisioning > Analogs menu*

Basic Analog Configuration	
<b>ID</b>	Analog ID number.
<b>Enab</b>	Check this box to enable the analog.
<b>Description</b>	User-definable description for the analog channel.
<b>Notification Devices</b>	Check which notification device(s), 1 through 8, you want to send alarm notifications for that alarm point.
Advanced Analog Configuration (Details>>)	
<b>Record Freq</b>	The amount of time, in minutes (min) or seconds (s), between each log of each analog value to history.
<b>Deadband</b>	The amount (in volts) that the channel needs to go above or below a threshold in order to cause an alarm.
<b>On Set</b>	User-definable description (condition) that will appear for the temperature alarm on Set. Example: "Alarm".
<b>On Clear</b>	User-definable description (condition) that will appear for the temperature alarm Clear. Example: "Alarm Cleared".
<b>Qual Time (Qualification Time)</b>	The length of time that must pass, without interruption, in order for the condition to be considered an Alarm or a Clear.
<b>Qual. Type (Qualification Type)</b>	Allows you to choose whether you want to apply the Qualification Time to the alarm Set, Clear, or Both.
<b>Units</b>	User-definable display units or optional choice between Fahrenheit and Celsius



	<p>temperatures. The most common are:</p> <p>VDC = Voltage  %H = Humidity  F = Fahrenheit  C = Celsius</p>
<b>Low Ref</b>	User-definable lower reference/scaling level. This scales the information collected by the sensor (in mA or VDC) to a meaningful unit for the user. For example, for a temperature sensor, the lower input collected by the sensor may be 4mA (for a 4-20mA sensor), which would correspond to a specific temperature you define in this field.
<b>High Ref</b>	User-definable upper reference/scaling level. This scales the information collected by the sensor (in mA or VDC) to a meaningful unit for the user. For example, for a temperature sensor, the upper input collected by the sensor may be 20mA (for a 4-20mA sensor), which would correspond to a specific temperature you define in this field.
<b>Thresholds</b>	These settings are set to indicate the severity of the alarm depending on which threshold values have been passed. Enter values for Major Under (MjU), Minor Under (MnU), Minor Over (MnO), and Major Over (MjO).
<b>Analog Gauge Type</b>	Select the color-coded gauge that best represents your data. Selecting <b>None</b> will disable the analog gauge and only a numerical representation of the value will be displayed under <b>Monitor &gt; Analogs</b> .




## 6.12 Sensors

The unit supports up to 16 daisy-chained D-Wire sensors via its D-Wire input. Sensors connected to the unit will appear on the unit's web interface. The background color of the ROM field informs the user of the sensor's configuration state.

Also, the unit's first D-Wire sensor is used to monitor the internal temperature. The internal temperature sensor measures a range of -40° F to 180° F (-40° C to 82.2° C) within an accuracy of about ± 2°.

Basic configuration for the unit's D-Wire temperature sensors can be accomplished from the **Provisioning > Sensors** menu. From this screen, you can configure D-Wire sensors, select notification devices, and set thresholds.

**Sensors** ( ■ - detected and configured ■ - detected and NOT configured ■ - NOT detected and configured ■ - sensor type NOT supported )

Id	ROM ID	Description	1	2	3	4	5	6	7	8
1	2025290c000000ab	Humidity <a href="#">Details&lt;&lt;</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<p>Record Freq: <input type="text" value="5min"/></p> <p>Deadband: <input type="text" value="1"/></p> <p>On Set: <input type="text" value="Alarm"/></p> <p>On Clear: <input type="text" value="Clear"/></p> <p>Qual. Time: <input type="text" value="0sec"/></p> <p>Qual. Type: <input type="text" value="OnSet"/></p>			<p><b>Sensor Type:</b></p> <p><input type="radio"/> Temperature</p> <p><input checked="" type="radio"/> Humidity</p>		<p>Thresholds:</p> <p>MjU: <input type="text" value="32"/></p> <p>MnU: <input type="text" value="42"/></p> <p>MnO: <input type="text" value="110"/></p> <p>MjO: <input type="text" value="158"/></p>					
<p><b>Analog Gauge Type:</b></p> <p>None    </p> <p><input type="radio"/> <input type="radio"/> <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/></p>										
2	2850cc77030000f9	Temperature <a href="#">Details&gt;&gt;</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	2809c83b040000d6	Internal Temperature <a href="#">Details&gt;&gt;</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	28596e7c020000e0	External Temperature <a href="#">Details&gt;&gt;</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5	224bf22400000043	Air Temperature <a href="#">Details&gt;&gt;</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6	3db1720150070068	Humidity 2 <a href="#">Details&gt;&gt;</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

The Provisioning > Sensors menu

Basic Sensor Configuration	
<b>ID</b>	Sensor ID number.
<b>ROM ID</b>	<p>The ID number found on the sticker of the temperature sensor node. Your unit will automatically detect the sensor ID when you plug a sensor into the unit. The color of the sensor ID field will tell you the status of the connected sensor.</p> <p><b>Green</b> - The sensor is connected and properly configured.</p> <p><b>Yellow</b> - The sensor is connected but has not yet been configured (fill in your configuration fields and click <b>Save</b> to configure the sensor).</p> <p><b>Red</b> - The sensor is not detected and configured (i.e. a previous configured sensor is no longer connected).</p> <p><b>Blue</b> - The sensor is not supported by the unit.</p> <p>To reconfigure or disable the Sensor ID, simply delete any data in this field and click <b>Save</b>.</p> <p>The unit will refresh the sensor ID on that channel.</p>
<b>Description</b>	User-definable description for the sensor channel.
<b>Notification Devices</b>	Check which notification device(s), 1 through 8, you want to send alarm notifications for that alarm point.
Advanced Sensor Configuration (Details>>)	
<b>Record Freq</b>	The amount of time, in minutes (min) or seconds (s), between each recorded sensor value.
<b>Deadband</b>	The amount (in native units) that the channel needs to go above or below a threshold in order to cause an alarm.
<b>On Set</b>	User-definable description (condition) that will appear for the temperature alarm on Set. Example: "Alarm".
<b>On Clear</b>	User-definable description (condition) that will appear for the temperature alarm Clear. Example: "Alarm Cleared".
<b>Qual Time (Qualification Time)</b>	The length of time that must pass, without interruption, in order for the condition to be considered an Alarm or a Clear.
<b>Qual. Type (Qualification Type)</b>	Allows you to choose whether you want to apply the Qualification Time to the alarm Set, Clear, or Both.
<b>Thresholds</b>	These settings are set to indicate the severity of the alarm depending on which threshold values have been passed. Enter values for Major Under (MjU), Minor Under (MnU), Minor Over (MnO), and Major Over (MjO).
<b>Analog Gauge Type</b>	Select the color-coded gauge that best represents your data. Selecting <b>None</b> will disable the analog gauge and only a numerical representation of the value will be displayed under <b>Monitor &gt; Sensors</b> .

**Note:** Before plugging in any additional D-Wire Sensors, set up the internal sensor.

## 6.13 Ping Targets

The **Provisioning > Ping Targets** menu allows you to configure the Description, IP Address, and Notification Devices for each of your 32 ping targets.

Ping Targets												
<b>Id</b>	<b>Enab</b>	<b>Description <a href="#">Display Map</a></b>	<b>Server (IP or Hostname)</b>	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>	
1	<input type="checkbox"/>	Cisco Router	126.102.218.3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
2	<input type="checkbox"/>	Ethernet Switch 1	126.102.218.24	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
3	<input type="checkbox"/>	Ethernet Switch 2	126.102.218.12	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
4	<input type="checkbox"/>	Ethernet Switch 2	126.102.218.14	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
5	<input type="checkbox"/>	Router 2	126.102.218.67	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
6	<input type="checkbox"/>	Media Converter	126.102.218.29	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
7	<input type="checkbox"/>	Microwave Transmitter	126.102.218.90	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
8	<input type="checkbox"/>	Cisco 15454	126.102.218.43	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
9	<input type="checkbox"/>	Calix	126.102.218.31	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
10	<input type="checkbox"/>	Modem	126.102.218.7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
11	<input type="checkbox"/>	PBX	126.102.218.15	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12	<input type="checkbox"/>	Proxy Server	126.102.218.39	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

*The Provisioning > Ping Targets menu*

Provisioning Ping Targets	
<b>ID</b>	ID number for the ping target.
<b>Enab</b>	Check this box to enable the ping target.
<b>Description</b>	User-definable description for the ping target.
<b>Server (IP or Hostname)</b>	IP address or hostname of the device you would like to ping.
<b>Notification Devices</b>	Check which notification device(s), 1 through 8, you want to send alarm notifications for ping target.

## 6.14 Variable Bindings

**Note:** Variable bindings are used when setting up SNMP alarms.

Variable Bindings	
Id	OID
1	<input type="text" value="0"/>
2	<input type="text" value="0"/>
3	<input type="text" value="0"/>
4	<input type="text" value="0"/>
5	<input type="text" value="0"/>
6	<input type="text" value="0"/>
7	<input type="text" value="0"/>
8	<input type="text" value="0"/>
9	<input type="text" value="0"/>
10	<input type="text" value="0"/>
11	<input type="text" value="0"/>

*The Provisioning > Variable Bindings menu*

Provisioning Variable Bindings	
<b>Id</b>	Identification number for the variable binding.
<b>OID</b>	OID of the variable binding. <b>Note:</b> Using a * in this field is like a "wild card" - any value is accepted.

## 6.15 SNMP Alarms

**SNMP Alarms**

Id	Description <a href="#">Display Map</a>	1	2	3	4	5	6	7	8															
1	Alarm 1 <a href="#">Details&lt;&lt;</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>															
<table border="1"> <thead> <tr> <th>Enterprise/OID</th> <th>Generic</th> <th>Specific</th> <th>Variable Binding</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Set: 0</td> <td>warmStart(1)</td> <td>0</td> <td>None</td> <td></td> </tr> <tr> <td>Clear: 0</td> <td>authenticationFailure(4)</td> <td>0</td> <td>None</td> <td></td> </tr> </tbody> </table>										Enterprise/OID	Generic	Specific	Variable Binding	Value	Set: 0	warmStart(1)	0	None		Clear: 0	authenticationFailure(4)	0	None	
Enterprise/OID	Generic	Specific	Variable Binding	Value																				
Set: 0	warmStart(1)	0	None																					
Clear: 0	authenticationFailure(4)	0	None																					
2	Alarm 2 <a href="#">Details&gt;&gt;</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>															
3	Alarm 3 <a href="#">Details&gt;&gt;</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>															
4	Alarm 4 <a href="#">Details&gt;&gt;</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>															

*The Provisioning > SNMP Alarms menu*

SNMP Alarms Settings	
<b>ID</b>	SNMP Alarm ID number.
<b>Description</b>	User-definable description for the SNMP alarm.
<b>Notification Devices</b>	Check which notification device(s), 1 through 8, will send alarm notifications in response to this SNMP alarm.

Advanced SNMP Alarms Settings (Details>>)	
<b>Enterprise/OID</b>	Enterprise OID for SNMPv1 or Trap OID for SNMPv2c.
<b>Generic</b>	Generic Trap number for <b>SNMP v1 only</b> .
<b>Specific</b>	Specific Trap number for <b>SNMPv1 only</b> .
<b>Variable Binding</b>	If defined, additional OID (from equipment connected to control relay) to uniquely identify the SNMP trap.
<b>Value</b>	Value of the variable binding. Must be integer or string (when searching for a specific string, the string must be contained within the received trap variable binding value). <b>Note:</b> Using a * in this field is like a "wild card" - any value is accepted.

## 6.16 System Alarms

See "Display Mapping" in the Reference Section for a complete description of system alarms.

System Alarms										
Pnt	Description <a href="#">Display Map</a>	Silence	1	2	3	4	5	6	7	8
33	Default configuration	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
34	DCP poller inactive	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
39	SNMP community error	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
41	Notification 1 failed	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
42	Notification 2 failed	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
43	Notification 3 failed	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
44	Notification 4 failed	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

*The Provisioning > System Alarms menu*

Editing System Alarms	
<b>Pnt (Point)</b>	The system alarm point number
<b>Description</b>	Non-editable description for this System (housekeeping) Alarm.
<b>Silence</b>	Check this box to choose to silence this alarm.
<b>Notification Devices</b>	Check which notification device(s), 1 through 8, you want to send alarm notifications for that alarm point.

### 6.16.1 SMS Alarm (CellVoice 4 Only)

All incoming SMS messages to the device will be parsed. If the phone number of the SMS message matches one of the phone numbers in the "Phone List" menu, then (1) the content of the incoming message will be preserved and (2) the "SMS Alarm" System Alarm will be SET and (once all of the numbers on the "Phone List" have been forwarded the message) CLEARED. Once the device has forwarded the message to the numbers on the "Phone List" and the "SMS Alarm" has cleared, the device will read the next incoming SMS message and repeat the process.

Messages being sent to the device should be limited to 111 characters. Messages longer than 111 characters will be truncated to fit this limitation. When a message has been truncated, three dots ("...") will appear at the end of the message.

**Note:** Make sure that the "Send SMS" or "Voice/SMS" notification that is associated with the "SMS Alarm" is set to "Notify on Alarms only".

## 6.17 Timers

The **Timers** are user-definable, and allow you to choose the intervals between **Web Refresh**, **Timed Tick**, **DCP Poller Timeout**, **Ping Cycle**, and **SNMP Timeout**. Enter the amount of time, in seconds (sec) or minutes (m), in the value field and click **Save**.

Timers	
<b>Web Refresh (1s-60s):</b> How often web browser is refreshed when in monitor mode.	1sec
<b>Timed Tick (0s-60m, 0=off):</b> This is a 'heartbeat' function that can be used by masters who don't perform integrity checks.	0sec
<b>DCP Poller Timeout (1m-30m, 0=off):</b> DCP polls must be received within this time interval or the DCP poller inactive alarm will set.	5min
<b>Ping Cycle (30s-30m, 0=off):</b> Time interval between each ping cycle.	4min
<b>SNMP Timeout (1m-30m, 0=off):</b> SNMP Get Requests must be received within this time interval. (Only used for Backup Mode)	5min
<b>WebTimeout (1m-30m):</b> Maximum idle time allowed before the web interface will automatically logout.	150sec
<input type="button" value="Save"/>	

*The Provisioning > Timers menu*

## 6.18 Date and Time

Date and Time			
<b>Unit Time</b>			
Date	Month	Day	Year
	Oct	8	2012
Time	Hour	Minute	PM
	12	25	PM
<input type="button" value="Set Unit Time"/>			
<b>Automatic Time Adjustment (NTP)</b>			
<input type="checkbox"/> Enable NTP			
NTP Server Address or Host Name			
Time Zone	GMT-08:00 Pacific Time		
<input type="button" value="Test NTP"/>			
<b>Adjust Clock for Daylight Saving Time (DST)</b>			
<input type="checkbox"/> Enable DST			
Start Day	Month	Weekday	Hour
	Mar	Second Sunday	2 AM
End Day	Month	Weekday	Hour
	Nov	First Sunday	2 AM
<input type="button" value="Save"/>			



The Provisioning > Date and Time menu

Unit Time	
<b>Date</b>	Set today's date.
<b>Time</b>	Set the current time.
Automatic Time Adjustment (NTP)	
<b>Enable NTP</b>	Check this box to enable Network Time Protocol.
<b>NTP Server Address or Host Name</b>	Enter the NTP server's IP address or host name, then click <b>Sync</b> . Example: us.pool.ntp.org. <b>Note:</b> Make sure to configure DNS before using host name instead of IP address.
<b>Time Zone</b>	Select your time zone from the drop-down menu.
Adjust Clock for Daylight Savings Time (DST)	
<b>Enable DST</b>	Check this box to have the unit observe Daylight Savings.
<b>Start Day</b>	Select the month, weekday, and time when Daylight Savings will begin.
<b>End Day</b>	Select the month, weekday, and time when Daylight Savings will end.

## 7 Monitoring via the Web Browser

### 7.1 Alarms (If Available)

This selection provides the status of the base alarms by indicating if an alarm has been triggered. Under the **State** column, the status will appear in red if an alarm has been activated. The status will be displayed in green when the alarm condition is not present.

Alarms		
Id	Description <a href="#">Display Map</a>	State
1	Front Door	Clear <input type="checkbox"/>
2	Tower Lights	Clear <input type="checkbox"/>
3	Commercial Power	Clear <input type="checkbox"/>
4	Router 1	Clear <input type="checkbox"/>

Click on Alarms in the Monitor menu to see if any base alarms have been triggered.

### 7.2 Controls (If Available)

Use the following rules to operate the unit's control:

1. Select **Controls** from the **Monitor** menu.
2. Under the **State** field, you can see the current condition of the control.
3. To issue the control, click on a command (**OPR** - operate, **RLS** - release, or **MOM** - momentary)

Controls			
Id	Description <a href="#">Display Map</a>	State	Command
1	Switch 1	Released <input type="checkbox"/>	<input type="button" value="OPR"/> <input type="button" value="RLS"/> <input type="button" value="MOM"/>

View and operate control relays from the Monitor > Controls menu

Control Relay Operation	
<b>ID</b>	ID number for the control relay.

<b>Description</b>	Description for the unit's control relay defined in the Provisioning > Controls menu.
<b>State</b>	Status of the control relay. Can either be <b>Released</b> or <b>Latched</b> .
<b>Command</b>	<b>OPR</b> - Latch the relay. <b>RLS</b> - Release the relay. <b>MOM</b> - Momentarily latch the relay, then automatically release the relay. The duration of the latch is defined in the Provisioning > Controls menu.

**Note:** The Commands will not appear if the control is derived.

## 7.3 Analogs (If Available)

The **Monitor > Analogs** screen provides a description of each analog channel, the current reading, the units being read, and alarm conditions (major under, minor under, major over, minor over) according to your temperature settings. If configured under **Provisioning > Analogs**, your analog values will be displayed as a graphical gauge. Selecting **Table View** will display a non-graphical interface of your values.


User Analogs ([Gauge View](#))

Id	Description <a href="#">Display Map</a>	Thresholds	Reading
2	Room Temperature	None	0.00 mA

Click on **Analogs** in the **Monitor** menu to view the current channel readings.

## 7.4 Sensors (If Available)

This selection provides the status of the system's analog channels by indicating if an alarm has been triggered. The **Monitor > Sensors** screen provides a description of each analog channel, the current reading, the units being read, and alarm conditions (major under, minor under, major over, minor over) according to your temperature settings. If configured under **Provisioning > Sensors**, your analog values will be displayed as a graphical gauge. Selecting **Table View** will display a non-graphical interface of your values.



The **Monitor > Sensors** menu

## 7.5 Ping Targets

Ping Targets can be viewed by going to **Monitor > Ping Targets**. Here you can view the state (either **Clear** or **Alarm**) for each of your configured Ping Targets. Up to 32 ping targets may be configured.

Ping Targets		
<b>Id</b>	<b>Description</b> <a href="#">Display Map</a>	<b>State</b>
1	Cisco Router	Clear
2	Ethernet Switch 1	Clear
3	Ethernet Switch 2	Clear
4	Ethernet Switch 2	Clear
5	Router 2	Clear
6	Media Converter	Clear
7	Microwave Transmitter	Clear
8	Cisco 15454	Clear
9	Calix	Clear
10	Modem	Clear
11	PBX	Clear
12	Proxy Server	Clear

*View the status of Ping Targets from the Monitor > Ping Targets menu.*

## 7.6 SNMP Alarms

This selection provides the status of the SNMP alarms by indicating if an alarm has been triggered. Under the **State** column, the status will appear in red if an alarm has been activated. The status will be displayed in green when the alarm condition is not present.








SNMP Alarms		
<b>Id</b>	<b>Description <a href="#">Display Map</a></b>	<b>State</b>
1		Clear <input type="checkbox"/>
2		Clear <input type="checkbox"/>
3		Clear <input type="checkbox"/>
4		Clear <input type="checkbox"/>
5		Clear <input type="checkbox"/>
6		Clear <input type="checkbox"/>
7		Clear <input type="checkbox"/>
8		Clear <input type="checkbox"/>
9		Clear <input type="checkbox"/>
10		Clear <input type="checkbox"/>
11		Clear <input type="checkbox"/>
12		Clear <input type="checkbox"/>

*The Monitor > SNMP Alarms menu*

## 7.7 System Alarms

System alarms are not-editable, housekeeping alarms that are programmed into the unit. The **Monitor > System Alarms** screen provides the status of the system alarms by indicating if an alarm has been triggered. Under the **State** column, the status will appear in red if an alarm has been activated. The status will be displayed in green when the alarm condition is not present.

See "Display Mapping" in the Reference Section for a complete description of system alarms.

System Alarms		
Pnt	Description <a href="#">Display Map</a>	State
33	Default configuration	Clear 
34	DCP poller inactive	Clear 
39	SNMP community error	Clear 
41	Notification 1 failed	Clear 
42	Notification 2 failed	Alarm 
43	Notification 3 failed	Clear 
44	Notification 4 failed	Clear 

*View the status of System Alarms from the Monitor > System Alarms menu.*

## 7.8 Alarm Log

**Alarm Log**

Evt	Date	Time	State	PRef	Description
1	05-04-10	14:05:44	Alarm	1.52	Unit reset
2	05-04-10	14:05:44	Clear	1.52	Unit reset
3	05-04-10	14:06:18	Alarm	1.56	Bad signal
4	05-04-10	14:06:43	Clear	1.56	Bad signal
5	05-04-10	14:07:34	Alarm	1.56	Bad signal
6	05-04-10	14:11:02	Clear	1.56	Bad signal
7	05-04-10	14:11:23	Alarm	1.56	Bad signal
8	05-04-10	14:11:48	Clear	1.56	Bad signal

*The Monitor > Alarm Log menu*

Alarm Log Operation	
<b>Pause Updates</b>	Temporarily prevents the table from updating, however events will continue to be internally logged. <b>Note:</b> Once you hit "Resume Updates," all internally logged events will appear.
<b>Clear Log</b>	Removes all visible events from the Alarm Log.

## 8 Device Access Descriptions

The **Device Access** options, listed in pink on the left side of the web interface, provide options for generating reports, updating the unit's firmware, and rebooting the unit. Click any of the options under **Device Access** to perform the desired action.



*The control menu is located in the bottom left of the web interface*

Device Access Option	Description
<b>Backup Config</b>	Backs up the units configuration settings
<b>Read</b>	Reads a configuration file from the unit
<b>Write</b>	Commits all changes made in the web interface to the unit's non-volatile memory
<b>Initialize</b>	Sets the unit's configuration to factory default values
<b>Get Log</b>	Opens the unit's event log in Notepad (or another plain text editor).
<b>Purge Log</b>	Deletes the unit's event log history.
<b>Reboot</b>	Reboots the unit.



## 9 Reference Section

### 9.1 Mounting Instructions

#### Tools Needed:



Phillips No. 2 Screwdriver



Small Standard  
No. 2 Screwdriver




Wire Strippers



PC with terminal emulator,  
such as HyperTerminal

The compact unit occupies only half the width of a standard rack unit. 19" rack ears are supplied with the unit. The unit mounts in a 19" or 23" rack, and can be mounted on the right or left, or rear mount locations, as shown below.



*Use the included wall mount bracket to mount the CellVoice vertically on the wall*

#### Wall-Mounting Instructions

The rack ears can be rotated 90° for wall mounting or 180° for other mounting options (not shown).

1. Depending on your order options, you will can attach wall-mount flanges to both sides of the unit in one of two ways:

- a. Place the flange over the protruding screws and fasten it to the 3/8" hex nuts provided.
- b. OR Fasten the flange to the unit with two of the 6/32 screws provided. (**NOTE:** Screws longer than

those provided may contact the internal components of the unit, adversely affecting its normal operation.)

2. After flanges have been attached to the unit, mount the unit in the desired location with two screws through each flange.



*The CellVoice 4 also mounts on your 19" or 23" equipment racks*

### **Rack-Mounting Instructions**

The unit mounts onto one side of a 19" or 23" rack using the provided rack ear for either size. The ear can be rotated 180 degrees during installation to adjust the position of the unit relative to the rack. Attach the appropriate ear to the rack in the desired location.


## 9.2 Firmware Upgrade

To access the **Firmware Load** screen, click on the **Provisioning > System** menu. At the bottom of this screen, click the **Restore Configuration** link located in the **System Controls** section.




To upload firmware, click on **Upload** on the top right corner of the web interface

At the **Firmware Load** screen, simply browse for the firmware update you've downloaded from [www.dpstele.com](http://www.dpstele.com) and click **Load**.



Browse for downloaded firmware upgrade

## 9.3 Front and Back Panel LED



LED	Status	Description
<b>Relay</b>	Green	When relay is operated (latched)
	Off	When relay is in released state
<b>Status</b>	Flashing Green	Application is running
	Flashing Red	Boot Loader is running
<b>Alarms (1-4)*</b>	Flashing Red	New alarm
	Solid Red	Standing alarm acknowledged
<b>Voice/Data</b>	Flashing Green	Good signal
	Flashing Red	Bad signal
<b>Wireless (Modem)</b>	Flashing Green	Transmitting to the modem
	Flashing Red	Receiving from the modem
<b>Power</b>	Solid Green	Power supply OK
	Off	No voltage or power leads reversed

*Front Panel LED Descriptions*

*\*If DCP is disabled, the Alarm LED will go Solid Red without acknowledgment.*




LED	Status	Description
PWR A/B	Solid Green	Power supply OK
	Off	No voltage or power leads reversed
LNK	Solid Green	LAN Connected
LAN	Flashing Green	Transmit and receive activity over Ethernet port
FA	Solid Red	Blown Fuse
100BT	Solid Green	LAN connection speed is 100BaseT
	Off	LAN connection speed is 10BaseT
Craft	Flashing Green	Transmitting data over craft port
	Flashing Red	Receiving data over craft port
Sensor	Flashing Green	Transmitting
	Flashing Red	Receiving

*Back Panel LED Descriptions*

## 9.4 Connecting to the unit via the Craft Port (using TTY Interface)

Another way to access the unit is over a physical cable connection between your PC's USB port and the unit's USB craft port. **Note:** You must be connected via craft port or Telnet to use the TTY interface. Make sure you are using a standard A-B USB cable (this same cable is commonly used for USB printers) to make a USB craft port connection. We'll be using HyperTerminal to connect to the unit in the following example - however, most terminal-emulating programs are also compatible.



**Note:** The following images display the setup process done in Windows XP.

The following steps will occur the first time any DPS USB equipment is used on this PC. If you've used a different DPS USB device before and have installed the DPS USB drivers, then **skip to Step 9**.


When you first connect the unit to your PC via USB, a "Found New Hardware" message will appear:




1. Click the "Found New Hardware" message/icon to launch the "Found New Hardware Wizard".



2. Select "Install from a list or specific location (Advanced)"
3. Click "Next >"



4. Select "Search for the best driver in these locations."
5. Insert CellVoice Resource Disc (CD) into your PC.
6. Click "Browse"



7. Select the "Driver" folder of your unit Resource Disc Disc (CD) and click "OK"


The following message will confirm installation of a new "USB Communications Port"



8. Click "Finish" to close the Wizard.

Now that the driver has been installed, a new COM port is being emulated on your PC. Before using hyperterminal, you must confirm the identity of that new COM port (COM1, COM2, COM3...) in the Windows Device Manager.






9. Right-click the "My Computer" icon on your desktop, then click "Manage"



10. Click "Device Manager" in the left pane.



11. Expand the "Ports (COM & LPT)" section in the right pane. Look for "USB Communications Port (COMx)". Note the number of the COM port ("COM3" in the example above).

Now that you know which COM port to use, it's time to launch HyperTerminal (or other terminal software):


12. Click on the **Start** menu > select **Programs > Accessories > Communications > HyperTerminal**.



13. At the Connection Description screen, enter a name for this connection. You may also select an icon. The name and icon do not affect your ability to connect to the unit.




14. At the Connect To screen, use the drop-down menu to select the COM port you found earlier in the Device Manager.




15. Select the following COM port options:

- Bits per second: 9600
- Data bits: 8
- Parity: None
- Stop bits: 1
- Flow control: **None**


Once connected, you will see a blank, white HyperTerminal screen. Press Enter to activate the configuration menu.




16. When prompted, enter the default user name **admin** and password **dpstelecom**. **NOTE:** If you don't receive a prompt for your user name and password, check the Com port you are using on your PC and make sure you are using the cable provided. Additional cables can be ordered from DPS Telecom.



17. The unit's main menu will appear. Type C for C)onfig, then E for E)thernet. Configure the unit's IP address, subnet mask, and default gateway.



18. ESC to the main menu. When asked if you'd like to save your changes, type Y for Y)es. Reboot the unit to save its new configuration.



```
Telnet 10.0.4.4
Linked      : Yes
DHCP       : Disabled
HTTP       : Enabled
RADIUS     : Allowed but not configured
Host Name  :
Unit IP    : 10.0.4.4      <10.0.4.4>
Subnet Mask : 0.0.0.2     <255.255.0.0>
Gateway    : 10.0.0.254  <10.0.0.254>
Unit MAC   : 00:10:81:00:69:70 <00:10:81:00:69:70>

U)nit Addr S)ubnet G)ateway D)HCP H(T)IP R)ADIUS H)ost <ESC> ? <--
E)thernet D)CP S)tats v<O>lume n<U>ran
re<B>oot <ESC> ?

Do you want to save changes <y/N> :
```

**Now you're ready** to do the rest of your configuration via LAN. Plug the unit into your LAN and see the "Logging On to the unit" section to continue databasing using the Web Browser.

## 9.4.1 TTY Interface

The TTY interface is the unit's built-in interface for basic configuration. From the TTY interface, you can:


- Edit the IPA, subnet, and gateway
- Set unit back to factory defaults
- Disable RADIUS
- Communicate with Modem
- Set DCP info for T/Mon polling
- Ping other devices on the network
- Debug and troubleshoot

*For more advanced configuration tools, please use the Web Browser Interface.*

For Telnet, connect to the IP address at port 2002 to access the configuration menus after initial LAN/WAN setup.

**Telnet sessions are established at port 2002.**

If you're using Windows 7, then you'll need to install telnet before you can use the TTY interface. To install telnet, open up your command line (type "cmd" into the search bar in the **Start Menu**). Select **cmd.exe** to run the command line.




From the command line, type in **pkgmgr /iu:"TelnetServer"** then press **enter**. When the command prompt appears again, the installation is complete.

### Menu Shortcut Keys

The letters before or enclosed in parentheses () are menu shortcut keys. Press the shortcut key to access that option. Pressing the ESC key will always bring you back to the previous level. Entries are not case sensitive.

## 9.4.2 Set DCP Parameters



*Setting DCP Parameters*

1. Login to the TTY interface and press C)onfig > D)CP.
2. Set the DCP Address (Unit ID).
3. Set the DCP listening type (toggle through the options). Choose over LAN\*, or disabled.

**Note:** If not using DCP to communicate with a DPS master, set the address to 0 and disable listening.

## 9.5 Setting up Backup Mode

This section will guide you through the process of setting up Backup Mode. Backup Mode is a system alarm feature capable of alerting you in the instance that DCP, SNMP, or a Notification fails. Even in instances LAN failure, Backup Mode works wirelessly with Voice and SMS notifications to make sure that you receive an alert (CellVoice 4 only)

### To setup Backup Mode:

1. Set the conditions for Backup Mode in the **Provisioning > Backup Mode** menu. Backup Mode will remain inactive until a checked condition fails. Once a checked condition fails, the Backup Mode alarm will be activated.

**Backup Mode**

DCP Fail	<input type="checkbox"/>
SNMP Fail	<input type="checkbox"/>
Notification 1	<input checked="" type="checkbox"/>
Notification 2	<input checked="" type="checkbox"/>
Notification 3	<input type="checkbox"/>
Notification 4	<input type="checkbox"/>
Notification 5	<input type="checkbox"/>
Notification 6	<input type="checkbox"/>
Notification 7	<input type="checkbox"/>
Notification 8	<input type="checkbox"/>
User Defined - Display: <input type="text" value="1"/> Point: <input type="text" value="1"/> <a href="#">Display Map</a>	<input type="checkbox"/>

Backup Mode is a System Alarm and its status can be viewed from the **Monitor > System Alarms** menu.

**System Alarms**

Pnt	Description <a href="#">Display Map</a>	State
33	Default configuration	Clear 
34	DCP poller inactive	Clear 
39	SNMP community error	Clear 
41	Notification 1 failed	Clear 
42	Notification 2 failed	Alarm 
43	Notification 3 failed	Alarm 
44	Notification 4 failed	Clear 
45	Notification 5 failed	Clear 
46	Notification 6 failed	Clear 
47	Notification 7 failed	Clear 
48	Notification 8 failed	Clear 
49	NTP failed	Clear 
50	Timed tick	Clear 
51	Dynamic memory full	Clear 
52	Unit reset	Clear 
55	Modem failed	Alarm 
56	Bad signal	Clear 
57	Backup Mode	Alarm 

## 9.5.1 How to Setup Voice Call or SMS Notifications in Backup Mode Only (CellVoice 4 only)

You can choose to have the CellVoice send you an SMS or Voice notification in the instance that a condition fails and Backup Mode becomes active. After choosing the conditions of Backup Mode, as outlined in **Section 10.5**, proceed to the steps below.

### To setup Voice Call or SMS Notifications in Backup Mode Only:

You can choose to have the CellVoice send you an SMS or Voice notification in the instance that a condition fails and Backup Mode becomes active. In order to do this, you will need to create a Backup Mode notification. After choosing the conditions of Backup Mode, as outlined in **Section 10.5** "Setting up Backup Mode," proceed to the steps below.

1. Navigate to **Provisioning > Notifications**.
2. Choose a notification and click "Edit." Backup Mode is configured to use wireless Voice and SMS notifications, so select either **Voice Call** or **Send SMS**. Fill out the information and check the box next to **Send notification only if in Backup Mode**. By checking this box, this notification will not be sent unless Backup Mode becomes active.
3. Click **Save and Next**, and finish configuring the notification.

Notification 3 (SMS)	
Phone Number or Email Address	<input type="text" value="555-555-5555"/>
Email Gateway	<input type="text" value="None"/> <b>This is required for SMS-to-Email</b>
Backup Mode	<input checked="" type="checkbox"/> <b>Send notification only if in Backup Mode.</b>
<input type="button" value="Back"/> <input type="button" value="Save and Next"/>	

**Note:** For more detailed information on configuring notifications, see sections **11.7.1** "Notification Settings," **10.3** "How to Send Voice Call Notifications," or **10.4** "How to Send SMS Notifications."



4. After setting up your Backup Mode notification, you will need to assign that notification to an alarm. Backup Mode notifications are typically used to alert you in instances that LAN-based notifications fail to deliver. You can assign your Backup Mode to an alarm by checking the notification number on the **Provisioning > Alarms** menu.

The screenshot shows two pages from the CellVoice 16 web interface. The top page is the 'Notifications' configuration page, and the bottom page is the 'Alarms' configuration page. A red circle highlights the notification with ID 3 in the Notifications table. A red line connects this circle to the '3' checkbox in the Alarms table, indicating that notification 3 is assigned to alarm 3.

**Notifications Table:**

Id	Notify On	Type	Details	Edit	Test
1	Both	SNMP	126.10.230.172:162	<input type="button" value="Edit"/>	<input type="button" value="Test"/>
2	Both	Email	126.10.230.172:162 / email@dpstele.net	<input type="button" value="Edit"/>	<input type="button" value="Test"/>
3	Both	SMS	555-555-5555	<input type="button" value="Edit"/>	<input type="button" value="Test"/>
	Disabled	Email	?	<input type="button" value="Edit"/>	<input type="button" value="Test"/>
	Disabled	Email	?	<input type="button" value="Edit"/>	<input type="button" value="Test"/>
	Disabled	Email	?	<input type="button" value="Edit"/>	<input type="button" value="Test"/>
	Disabled	Email	?	<input type="button" value="Edit"/>	<input type="button" value="Test"/>
	Disabled	Email	?	<input type="button" value="Edit"/>	<input type="button" value="Test"/>

**Alarms Table:**

Id	Description	Display Map	Rev.	1	2	3	4	5	6	7	8
1	Alm 1	<input type="text"/>	Advanced<<	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	SERVER ROOM	<input type="text"/>	Advanced>>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	WEST SIDE DOOR	<input type="text"/>	Advanced>>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	RECTIFIER	<input type="text"/>	Advanced>>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5	MICROWAVE	<input type="text"/>	Advanced>>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

**Note:** The CellVoice cycles through alarm notifications in numerical order. This means that Backup Mode notifications should be placed last, behind all other alarms to ensure that they are delivered after all other notifications have failed.

## 9.6 Setting Up SMS for RRM (Rapid Response Monitoring)

This section will guide you through the process of setting up SMS notification to send to the RRM (Rapid Response Monitoring) service.

To setup SMS notification for RRM:

1. In the "Provisioning > System" menu:
  - a. Add the correct account number in the "Contact/Account" section.
    1. This will add the correct Account to the SMS message.

### System Settings

Global Settings	
Name	CellVoice 4
Location	Fresno, CA
Contact/Account	559-454-1600
DTMF Pass Code	<input type="text"/> (Used when user first dials into the unit)
DTMF Record Pass Code	1234 (Used when user wants to record a description)
Rings Before Pickup	3

2. In the "Provisioning > Alarms" menu:
  - a. Click on the "Advanced" link for one of the alarms.
  - b. Using the "Severity" drop-down menu, select one of the choices (Critical = "Panic", Major = "NoiseDet", Minor = "Motion", Info = "AreaDet")
    1. This will add the correct Code to the SMS message.

### Alarms

Id	Description	<a href="#">Display Map</a>	Rev.	1	2	3	4	5	6	7	8
1	<input type="text"/>	<a href="#">Advanced&lt;&lt;</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
On Set: <input type="text" value="Alarm"/> On Clear: <input type="text" value="Clear"/> Qual. Time: <input type="text" value="0sec"/> Qual. Type: <input type="text" value="OnSet"/> Severity: <input type="text" value="None"/>											
2	<input type="text"/>	<a href="#">Adv</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	<input type="text"/>	<a href="#">Adv</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	<input type="text"/>	<a href="#">Advanced&gt;&gt;</a>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

3. In the "Provisioning > Phone List" menu:
  - a. Add the description and phone number for the RRM service.
  - b. Select "SMS-Mon" in the "Msg Type" column and enable the phone number.

**Phone List**

Save

Slot	Enab	Msg Type	Description	Phone Number
1	<input checked="" type="checkbox"/>	SMS-Mon	Tech1	559-454-1600
2	<input type="checkbox"/>	Voice Call		
3	<input type="checkbox"/>	SMS-Mon		

4. In the "Provisioning > Notifications" menu:
  - a. Click "Edit" for one of the notifications.

**Notifications**

Summary

Id	Notify On	Type	Details	
1	Disabled	Email	Server Not Configured	Edit Test
2	Disabled	Email	Server Not Configured	Edit Test
3	Disabled	Email	Server Not Configured	Edit Test
4	Disabled	Email	Server Not Configured	Edit Test
5	Disabled	Email	Server Not Configured	Edit Test
6	Disabled	Email	Server Not Configured	Edit Test
7	Disabled	Email	Server Not Configured	Edit Test
8	Disabled	Email	Server Not Configured	Edit Test

- b. Edit on of the notifications as a "Voice /SMS" type notification.

**Notification 1**

Status: Notify on both Alarms and Clears

Type:
 

- Send Email
- Send SNMP
- Voice/SMS
- Send SMS

Back Save and Next

- c. Select the phone number set-up in Step 1 as one of the Phone Numbers.

### Notification 1 (Voice/SMS)

Back Save and Next

Id	Phone Number to Call (Click "Phone List" to add phones)	Delay
1	559-454-1600 (Tech1) SMS-Mon	1min
2	559-454-1600 (Tech1) SMS-Mon	1min
3	Phone List slot 2 has no number!	1min
4	Phone List slot 3 has no number!	1min
5	Phone List slot 4 has no number!	1min
6	Phone List slot 5 has no number!	1min
7	Phone List slot 6 has no number!	1min
8	Phone List slot 7 has no number!	1min
9	Phone List slot 8 has no number!	1min
10	Phone List slot 9 has no number!	1min
11	Phone List slot 10 has no number!	1min
12	Phone List slot 11 has no number!	1min
13	Phone List slot 12 has no number!	1min
14	Phone List slot 13 has no number!	1min
15	Phone List slot 14 has no number!	1min
16	Phone List slot 15 has no number!	1min
17	Phone List slot 16 has no number!	1min
18	Phone List slot 17 has no number!	1min
19	Phone List slot 18 has no number!	1min
20	Phone List slot 19 has no number!	1min
21	EMPTY	1min

5. Set this notification for the alarms of your choice.

## 9.7 Changing the Default Password

The password can be configured from the **Provisioning > User Profiles** screen. The minimum password length is four characters; however, DPS recommends setting the minimum password length to at least five characters.

Use the following steps to change the logon password:

1. From the **Edit** menu select **System**.
2. Enter the new user name in the **User** field.
3. Enter the new password in the **Password** field.
4. Click the **Save** button.

**User Profile 1 (Administrator Profile)**

<b>Suspend this Profile</b>	<input type="checkbox"/>
<b>Username</b>	admin
<b>Password</b>	.....
<b>Confirm Password</b>	.....
<b>Access Rights</b>	
<b>Check all</b>	<input type="checkbox"/>
<b>Edit logon profiles</b>	<input checked="" type="checkbox"/>
<b>Write config (change unit configuration)</b>	<input checked="" type="checkbox"/>
<b>View monitor pages</b>	<input checked="" type="checkbox"/>
<b>Send relay commands</b>	<input checked="" type="checkbox"/>
<b>TTY access (access via Craft port or via Telnet)</b>	<input checked="" type="checkbox"/>
<b>Initialize config to factory defaults</b>	<input checked="" type="checkbox"/>
<b>Upload new firmware, description recordings, or config</b>	<input checked="" type="checkbox"/>
<b>Get audit log</b>	<input checked="" type="checkbox"/>
<b>Purge (delete) audit log</b>	<input checked="" type="checkbox"/>
<b>Get (backup) config</b>	<input checked="" type="checkbox"/>
<b>Get and delete analog history</b>	<input checked="" type="checkbox"/>
<b>Get and delete description recordings</b>	<input checked="" type="checkbox"/>
<input type="button" value="Save"/>	
<a href="#">Go to profiles summary</a>	

*Edit User Profile section of the Provisioning > User Profiles menu*

## 9.8 Analog Step Sizes

### Analog Step Sizes:

Your Analogs are accurate to within +/- 1% of the analog range.

Analog Step Sizes and Accuracy		
Input Voltage Range	Resolution (Step Size)	Accuracy
0-5 V	.0015 V	+/- .05V
5-14 V	.0038 V	+/- .14V
14-30 V	.0081 V	+/- .30V
30-70 V	.0182 V	+/- .70V
70-90 V	.0231 V	+/- .90V

*Analog step sizes and accuracy*

## 9.9 Display Mapping & System Alarms

	Description	Port	Address	Point
Display 1	Discrete Alarms	99	1	1-4
	Default Configuration	99	1	33
	DCP Poller Inactive	99	1	34
	SNMP Community Error	99	1	39
	Notification 1 Failed	99	1	41
	Notification 2 Failed	99	1	42
	Notification 3 Failed	99	1	43
	Notification 4 Failed	99	1	44
	Notification 5 Failed	99	1	45
	Notification 6 Failed	99	1	46
	Notification 7 Failed	99	1	47
	Notification 8 Failed	99	1	48
	NTP Failed	99	1	49
	Timed Tick	99	1	50
	Dynamic Memory Full	99	1	51
	Unit Reset	99	1	52
	Modem Failed	99	1	55
Bad signal	99	1	56	
Backup Mode	99	1	57	
SMS Alarm	99	1	58	
Display 2	Controls	99	1	1
	Ping Targets	99	1	33-64
Display 3	Power A Minor Under	99	1	1
	Power A Minor Over	99	1	2
	Power A Major Under	99	1	3
	Power A Major Over	99	1	4
	Control	99	1	9-16
	Value	99	1	17-32
	User Analog Minor Under	99	1	33
	User Analog Minor Over	99	1	34
	User Analog Major Under	99	1	35
	User Analog Major Over	99	1	36
	Control	99	1	41-48
	Value	99	1	49-64

<b>Display 4</b>	Digital sensor 1 Minor Under	99	1	1
	Digital sensor 1 Minor Over	99	1	2
	Digital sensor 1 Major Under	99	1	3
	Digital sensor 1 Major Over	99	1	4
	Digital sensor 1 Sensor not detected	99	1	5
	Control	99	1	9-16
	Value	99	1	17-32
	Digital sensor 2 Minor Under	99	1	33
	Digital sensor 2 Minor Over	99	1	34
	Digital sensor 2 Major Under	99	1	35
	Digital sensor 2 Major Over	99	1	36
	Digital sensor 2 Sensor not detected	99	1	37
	Control	99	1	41-48
	Value	99	1	49-64

Display	Description	Port	Address	Point
Display 5	Digital sensor 3 Minor Under	99	1	1
	Digital sensor 3 Minor Over	99	1	2
	Digital sensor 3 Major Under	99	1	3
	Digital sensor 3 Major Over	99	1	4
	Digital sensor 3 Sensor not detected	99	1	5
	Control	99	1	9-16
	Value	99	1	17-32
	Digital sensor 4 Minor Under	99	1	33
	Digital sensor 4 Minor Over	99	1	34
	Digital sensor 4 Major Under	99	1	35
	Digital sensor 4 Major Over	99	1	36
	Digital sensor 4 Sensor not detected	99	1	37
	Control	99	1	41-48
	Value	99	1	49-64
Display 6	Digital sensor 5 Minor Under	99	1	1
	Digital sensor 5 Minor Over	99	1	2
	Digital sensor 5 Major Under	99	1	3
	Digital sensor 5 Major Over	99	1	4
	Digital sensor 5 Sensor not detected	99	1	5
	Control	99	1	9-16
	Value	99	1	17-32
	Digital sensor 6 Minor Under	99	1	33
	Digital sensor 6 Minor Over	99	1	34
	Digital sensor 6 Major Under	99	1	35
	Digital sensor 6 Major Over	99	1	36
	Digital sensor 6 Sensor not detected	99	1	37
	Control	99	1	41-48
	Value	99	1	49-64
Display 7	Digital sensor 7 Minor Under	99	1	1
	Digital sensor 7 Minor Over	99	1	2
	Digital sensor 7 Major Under	99	1	3
	Digital sensor 7 Major Over	99	1	4
	Digital sensor 7 Sensor not detected	99	1	5
	Control	99	1	9-16
	Value	99	1	17-32
	Digital sensor 8 Minor Under	99	1	33
	Digital sensor 8 Minor Over	99	1	34
	Digital sensor 8 Major Under	99	1	35
	Digital sensor 8 Major Over	99	1	36
	Digital sensor 8 Sensor not detected	99	1	37
	Control	99	1	41-48
	Value	99	1	49-64

*Display Mapping (continued..)*



Display	Description	Port	Address	Point
Display 8	Digital sensor 9 Minor Under	99	1	1
	Digital sensor 9 Minor Over	99	1	2
	Digital sensor 9 Major Under	99	1	3
	Digital sensor 9 Major Over	99	1	4
	Digital sensor 9 Sensor not detected	99	1	5
	Control	99	1	9-16
	Value	99	1	17-32
	Digital sensor 10 Minor Under	99	1	33
	Digital sensor 10 Minor Over	99	1	34
	Digital sensor 10 Major Under	99	1	35
	Digital sensor 10 Major Over	99	1	36
	Digital sensor 10 Sensor not detected	99	1	37
	Control	99	1	41-48
	Value	99	1	49-64
Display 9	Digital sensor 11 Minor Under	99	1	1
	Digital sensor 11 Minor Over	99	1	2
	Digital sensor 11 Major Under	99	1	3
	Digital sensor 11 Major Over	99	1	4
	Digital sensor 11 Sensor not detected	99	1	5
	Control	99	1	9-16
	Value	99	1	17-32
	Digital sensor 12 Minor Under	99	1	33
	Digital sensor 12 Minor Over	99	1	34
	Digital sensor 12 Major Under	99	1	35
	Digital sensor 12 Major Over	99	1	36
	Digital sensor 12 Sensor not detected	99	1	37
	Control	99	1	41-48
	Value	99	1	49-64
Display 10	Digital sensor 13 Minor Under	99	1	1
	Digital sensor 13 Minor Over	99	1	2
	Digital sensor 13 Major Under	99	1	3
	Digital sensor 13 Major Over	99	1	4
	Digital sensor 13 Sensor not detected	99	1	5
	Control	99	1	9-16
	Value	99	1	17-32
	Digital sensor 14 Minor Under	99	1	33
	Digital sensor 14 Minor Over	99	1	34
	Digital sensor 14 Major Under	99	1	35
	Digital sensor 14 Major Over	99	1	36
	Digital sensor 14 Sensor not detected	99	1	37
	Control	99	1	41-48
	Value	99	1	49-64

*Display Mapping (continued..)*

Display	Description	Port	Address	Point
Display 11	Digital sensor 15 Minor Under	99	1	1
	Digital sensor 15 Minor Over	99	1	2
	Digital sensor 1 Major Under	99	1	3
	Digital sensor 15 Major Over	99	1	4
	Digital sensor 15 Sensor not detected	99	1	5
	Control	99	1	9-16
	Value	99	1	17-32
	Digital sensor 16 Minor Under	99	1	33
	Digital sensor 16 Minor Over	99	1	34
	Digital sensor 16 Major Under	99	1	35
	Digital sensor 16 Major Over	99	1	36
	Digital sensor 16 Sensor not detected	99	1	37
	Control	99	1	41-48
	Value	99	1	49-64
Display 12	SNMP Alarms	99	1	1-32
	Undefined	99	1	33-64

*Display Mapping (continued..)*

Display	Points	Alarm Point	Description	Solution
1	33	Default configuration	The internal NVRAM may be damaged. The unit is using default configuration settings.	Login to the unit's web browser and configure the unit. Power cycle to see if the alarm clears.
	34	DCP poller inactive	The unit is configured to listen for DCP polls but has not received a poll in over 5 minutes.	Check if unit can ping T/Mon or disable if not in use.
	41	Notification 1 failed	A notification 1 event, such as a page or email, was unsuccessful.	Verify that you can ping both devices.
	42	Notification 2 failed	A notification 2 event, such as a page or email, was unsuccessful.	Use RPT filter debug to help diagnose notification problems.
	43	Notification 3 failed	A notification 3 event, such as a page or email, was unsuccessful.	Use RPT filter debug to help diagnose notification problems.
	44	Notification 4 failed	A notification 4 event, such as a page or email, was unsuccessful.	Use RPT filter debug to help diagnose notification problems.
	45	Notification 5 failed	A notification 5 event, such as a page or email, was unsuccessful.	Use RPT filter debug to help diagnose notification problems.
	46	Notification 6 failed	A notification 6 event, such as a page or email, was unsuccessful.	Use RPT filter debug to help diagnose notification problems.
	47	Notification 7 failed	A notification 7 event, such as a page or email, was unsuccessful.	Use RPT filter debug to help diagnose notification problems.
	48	Notification 8 failed	A notification 8 event, such as a page or email, was unsuccessful.	Use RPT filter debug to help diagnose notification problems.
	49	NTP failed	Communication with Network Time Server has failed.	Try pinging the Network Time Server's IP Address as it is configured. If the ping test is successful, then check the port setting and verify the port is not being blocked on your network.
	50	Timed Tick	Toggles state at constant rate as configured by the Timed Tick timer variable. Useful in testing integrity of SNMP trap alarm reporting.	To turn the feature off, set the Timed Tick timer to 0.
	51	Dynamic memory full	Not expected to occur.	Call DPS Tech Support (559) 454-1600.
	52	Unit reset	Unit has rebooted.	If unintentional, call DPS Tech Support: (559) 454-1600.
	55	Modem failed	The Modem component to the unit has stopped responding.	Check if Modem is properly placed in socket. Contact DPS Tech Support (559) 454-1600.
56	Bad signal	The Wireless Modem does not detect a cellular signal. (CellVoice 4 only)	Ensure that the cellular antenna is properly connected to the CellVoice. If possible, reposition the CellVoice to find a cellular signal. If unsuccessful, contact DPS.	
57	Backup Mode	See Section 10.5, "Backup Mode."	Alarm specific.	

System Alarms Display Map


## 9.10 Voice Notification Flow Chart (CellVoice 4 only)

	Press 1	Press 2	Press 3	Press 4	Press 5	Press 6	Press 7	Press *	Press #
<b>Main Menu</b>	List Events	Acknowledge all Events	List Standing Alarms	Go to <b>Operate Relays</b>	-	-	-	Go to <b>More Options</b>	-
<b>More Options</b>	Record Descriptions, go to <b>Select Descriptions</b>	Report Analog Values	-	-	-	-	-	-	Return to <b>Main Menu</b>
<b>Select Description</b>	Select alarm description, go to <b>Record Description</b>	Select analog description, go to <b>Record Description</b>	Select relay description, go to <b>Record Description</b>	Select other descriptions, go to <b>Record Description</b>	Select alarm set description, go to <b>Record Description</b>	Select alarm clear description, go to <b>Record Description</b>	Select ping target description, go to <b>Record Description</b>	-	Return to <b>Main Menu</b>
<b>Record Description</b>	Play user description	Record user description	Delete user description	-	-	-	-	-	Return to <b>Select Description</b>
<b>Operate Relays</b>	*Operate Relay	*Release Relay	Momentary Operate Relay	-	-	-	-	-	Return to <b>More Options</b>

## 9.11 SNMP Manager Functions

The SNMP Manager allows the user to view alarm status, set date/time, issue controls, and perform a resync. The display and tables below outline the MIB object identifiers. Table 14.2 begins with dpsRTU; however, the MIB object identifier tree has several levels above it. The full English name is as follows:

root.iso.org.dod.internet.private.enterprises.dps-inc.dpsAlarmControl.dpsRTU. Therefore, dpsRTU's full object identifier is 1.3.6.1.4.1.2682.1.2. Each level beyond dpsRTU adds another object identifying number. For example, the object identifier of the Display portion of the Control Grid is 1.3.6.1.4.1.2682.1.2.3.3 because the object identifier of dpsRTU is 1.3.6.1.4.1.2682.1.4 + the Control Grid (.3) + the Display (.3).



\* Must be set to "1" to perform the resync request which will resend TRAPs for any standing alarm.

PntMap (.5)\*

<b>Tbl. B3 (.3) ControlGrid points</b>
<b>ControlGrid (1.3.6.1.4.1.2682.1.2.3)</b>
Port (.1)
Address (.2)
Display (.3)
Point (.4)
Action (.5)

<b>Tbl. B5 (.5) AlarmEntry points</b>
<b>AlarmEntry (1.3.6.4.1.2682.1.2.5.1)</b>
Aport (.1)
AAddress (.2)
ADisplay (.3)
APoint (.4)
APntDesc (.5)*
AState (.6)
* For specific alarm points, see Table B6

<b>Tbl. B6 (.6) Analog Channels</b>
<b>Channel Entry (1.3.6.1.4.1.2682.1.4.6.1)</b>
Channel Number (.1)
Enabled (.2)
Description (.3)
Value (.4)
Thresholds (.5)*
*If Mj, Mn is assumed

## 9.12 SNMP Granular Trap Packets

The tables below provide a list of the information contained in the SNMP Trap packets sent by the unit.

### SNMP Trap managers can use one of two methods to get alarm information:

1. Granular traps (not necessary to define point descriptions for the unit) **OR**
2. The SNMP manager reads the description from the Trap.

UDP Header	Description
1238	Source port
162	Destination port
303	Length
0xBAB0	Checksum

*UDP Headers and descriptions*

SNMP Header	Description
0	Version
Public	Request
Trap	Request
1.3.6.1.4.1.2682.1.4	Enterprise
126.10.230.181	Agent address
Enterprise Specific	Generic Trap
8001	Specific Trap
617077	Time stamp
1.3.7.1.2.1.1.1.0	Object
CellVoice v1.0K	Value
1.3.6.1.2.1.1.6.0	Object
1-800-622-3314	Value
1.3.6.1.4.1.2682.1.4.4.1.0	Object
01-02-1995 05:08:27.760	Value
1.3.6.1.4.1.2682.1.4.5.1.1.99.1.1.1	Object
99	Value
1.3.6.1.4.1.2682.1.4.5.1.2.99.1.1.1	Object
1	Value
1.3.6.1.4.1.2682.1.4.5.1.3.99.1.1.1	Object
1	Value
1.3.6.1.4.1.2682.1.4.5.1.4.99.1.1.1	Object
1	Value
1.3.6.1.4.1.2682.1.4.5.1.5.99.1.1.1	Object
Rectifier Failure	Value
1.3.6.1.4.1.2682.1.4.5.1.6.99.1.1.1	Object
Alarm	Value

*SNMP Headers and descriptions*

## 10 Frequently Asked Questions

Here are answers to some common questions from users. The latest FAQs can be found on the DPS support web page, <http://www.dpstele.com>.

If you have a question about the CellVoice or TrapRelay, please call us at **(559) 454-1600** or e-mail us at [support@dpstele.com](mailto:support@dpstele.com).

### 10.1 General FAQs

**Q. How do I telnet to the unit?**

**A.** You must use **Port 2002** to connect to the unit. Configure your Telnet client to connect using TCP/IP (**not** "Telnet," or any other port options). For connection information, enter the IP address of the unit and Port 2002. For example, to connect to the unit using the standard Windows Telnet client, click Start, click Run, and type "telnet <unit IP address> 2002."

**Q. How do I connect my unit to the LAN?**

**A.** To connect your unit to your LAN, you need to configure the unit IP address, the subnet mask and the default gateway. A sample configuration could look like this:

**Unit Address:** 192.168.1.100

**subnet mask:** 255.255.255.0

**Default Gateway:** 192.168.1.1

Save your changes by writing to NVRAM and reboot. Any change to the unit's IP configuration requires a reboot.

**Q. When I connect to the unit through the craft port on the front panel it either doesn't work right or it doesn't work at all. What's going on?**

**A.** Make sure your using the right COM port settings. Your COM port settings should read:

**Bits per second:** 9600 (9600 baud)

**Data bits:** 8

**Parity:** None

**Stop bits:** 1

**Flow control:** None

**Important!** Flow control **must** be set to **none**. Flow control normally defaults to hardware in most terminal programs, and this will not work correctly with the unit.

**Q. The LAN link LED is green on my unit, but I can't poll it from my T/Mon.**

**A.** Some routers will not forward packets to an IP address until the MAC address of the destination device has been registered on the router's Address Resolution Protocol (ARP) table. Enter the IP address of your gateway and your T/Mon system to the ARP table.

**Q. What characteristics of an alarm point can be configured through software? For instance, can point 4 be used to sense an active-low signal, or point 5 to sense a level or an edge?**

**A.** The unit's standard configuration is for all alarm points to be level-sensed. You **cannot** use configuration software to convert alarm points to TTL (edge-sensed) operation. TTL alarm points are a hardware option that must be specified when you order your unit. Ordering TTL points for your unit does not add to the cost of the unit. What you can do with the configuration software is change any alarm point from "Normal" to "Reversed" operation. Switching to Reversed operation has different effects, depending on the kind of input connected to the alarm point:

- **If the alarm input generates an active-high signal**, switching to Reversed operation means the unit will declare an alarm in the absence of the active-high signal, creating the practical equivalent of an active-low alarm.
- **If the alarm input generates an active-low signal**, switching to Reversed operation means the unit will declare an alarm in the absence of the active-low signal, creating the practical equivalent of an active-high alarm.

- **If the alarm input is normally open**, switching to Reversed operation converts it to a normally closed alarm point.
- **If the alarm input is normally closed**, switching to Reversed operation converts it to a normally open alarm point.

**Q. I'm unsure if the voltage of my power supply is within the specified range. How to I test the voltage?**

**A.** Connect the black common lead of a voltmeter to the ground terminal of the battery. Connect the red lead of the voltmeter to the batter's VCD terminal. The voltmeter should read between +12 and +30VDC.

## 10.2 SNMP FAQs

**Q. Which version of SNMP is supported by the SNMP agent on the unit?**

**A.** SNMP v1, SNMP v2c, and SNMP v3.

**Q. How do I configure the unit to send traps to an SNMP manager? Is there a separate MIB for the unit? How many SNMP managers can the agent send traps to? And how do I set the IP address of the SNMP manager and the community string to be used when sending traps?**

**A.** The unit begins sending traps as soon as the SNMP managers are defined. The unit MIB can be found on the DPS Telecom website. The MIB should be compiled on your SNMP manager. (**Note:** MIB versions may change in the future.) The unit supports 2 SNMP managers, which are configured by entering its IP address in the Trap Address field of Ethernet Port Setup. To configure the community strings, choose SNMP from the Edit menu, and enter appropriate values in the Get, Set, and Trap fields.

**Q. Does the unit support MIB-2 and/or any other standard MIBs?**

**A.** The unit supports the bulk of MIB-2.

**Q. Does the unit SNMP agent support both unit variables and T/MonXM variables?**

**A.** The unit SNMP agent manages an embedded MIB that supports only the unit's RTU variables. The T/MonXM variables are included in the distributed MIB only to provide SNMP managers with a single MIB for all DPS Telecom products.

**Q. How many traps are triggered when a single point is set or cleared? The MIB defines traps like "major alarm set/cleared," "RTU point set," and a lot of granular traps, which could imply that more than one trap is sent when a change of state occurs on one point.**

**A.** Generally, a single change of state generates a single trap.

**Q. What does "point map" mean?**

**A.** A point map is a single MIB leaf that presents the current status of a 64-alarm-point display in an ASCII-readable form, where a "." represents a clear and an "x" represents an alarm.

**Q. The unit manual talks about control relay outputs. How do I control these from my SNMP manager?**

**A.** The control relays are operated by issuing the appropriate set commands, which are contained in the DPS Telecom MIB.

**Q. How can I associate descriptive information with a point for the RTU granular traps?**

**A.** The unit alarm point descriptions are individually defined using the Web Browser.

**Q. My SNMP traps aren't getting through. What should I try?**

**A.** Try these three steps:

1. Make sure that the Trap Address (IP address of the SNMP manager) is defined. (If you changed the Trap Address, make sure you saved the change to NVRAM and rebooted.)
2. Make sure all alarm points are configured to send SNMP traps.
3. Make sure the unit and the SNMP manager are both on the network. Use the unit's ping command to ping the SNMP manager.



# 11 Technical Support

DPS Telecom products are backed by our courteous, friendly Technical Support representatives, who will give you the best in fast and accurate customer service. To help us help you better, please take the following steps before calling Technical Support:

**1. Check the DPS Telecom website.**

You will find answers to many common questions on the DPS Telecom website, at <http://www.dpstele.com/support/>. Look here first for a fast solution to your problem.

**2. Prepare relevant information.**

Having important information about your DPS Telecom product in hand when you call will greatly reduce the time it takes to answer your questions. If you do not have all of the information when you call, our Technical Support representatives can assist you in gathering it. Please write the information down for easy access. Please have your user manual and hardware serial number ready.

**3. Have access to troubled equipment.**

Please be at or near your equipment when you call DPS Telecom Technical Support. This will help us solve your problem more efficiently.

**4. Call during Customer Support hours.**

Customer support hours are Monday through Friday, from 7 A.M. to 6 P.M., Pacific time. The DPS Telecom Technical Support phone number is **(559) 454-1600**.

**Emergency Assistance:** *Emergency assistance is available 24 hours a day, 7 days a week. For emergency assistance after hours, allow the phone to ring until it is answered with a paging message. You will be asked to enter your phone number. An on-call technical support representative will return your call as soon as possible.*





## 12 End User License Agreement

All Software and firmware used in, for, or in connection with the Product, parts, subsystems, or derivatives thereof, in whatever form, including, without limitation, source code, object code and microcode, including any computer programs and any documentation relating to or describing such Software is furnished to the End User only under a non-exclusive perpetual license solely for End User's use with the Product.

The Software may not be copied or modified, in whole or in part, for any purpose whatsoever. The Software may not be reverse engineered, compiled, or disassembled. No title to or ownership of the Software or any of its parts is transferred to the End User. Title to all patents, copyrights, trade secrets, and any other applicable rights shall remain with the DPS Telecom.

DPS Telecom's warranty and limitation on its liability for the Software is as described in the warranty information provided to End User in the Product Manual.

End User shall indemnify DPS Telecom and hold it harmless for and against any and all claims, damages, losses, costs, expenses, obligations, liabilities, fees and costs and all amounts paid in settlement of any claim, action or suit which may be asserted against DPS Telecom which arise out of or are related to the non-fulfillment of any covenant or obligation of End User in connection with this Agreement.

This Agreement shall be construed and enforced in accordance with the laws of the State of California, without regard to choice of law principles and excluding the provisions of the UN Convention on Contracts for the International Sale of Goods. Any dispute arising out of the Agreement shall be commenced and maintained only in Fresno County, California. In the event suit is brought or an attorney is retained by any party to this Agreement to seek interpretation or construction of any term or provision of this Agreement, to enforce the terms of this Agreement, to collect any money due, or to obtain any money damages or equitable relief for breach, the prevailing party shall be entitled to recover, in addition to any other available remedy, reimbursement for reasonable attorneys' fees, court costs, costs of investigation, and other related expenses.





# Warranty

---

DPS Telecom warrants, to the original purchaser only, that its products a) substantially conform to DPS' published specifications and b) are substantially free from defects in material and workmanship. This warranty expires two years from the date of product delivery with respect to hardware and ninety days from the date of product delivery with respect to software. If the purchaser discovers within these periods a failure of the product to substantially conform to the specifications or that the product is not substantially free from defects in material and workmanship, the purchaser must promptly notify DPS. Within reasonable time after notification, DPS will endeavor to correct any substantial non-conformance with the specifications or substantial defects in material and workmanship, with new or used replacement parts. All warranty service will be performed at the company's office in Fresno, California, at no charge to the purchaser, other than the cost of shipping to and from DPS, which shall be the responsibility of the purchaser. If DPS is unable to repair the product to conform to the warranty, DPS will provide at its option one of the following: a replacement product or a refund of the purchase price for the non-conforming product. These remedies are the purchaser's only remedies for breach of warranty. Prior to initial use the purchaser shall have determined the suitability of the product for its intended use. DPS does not warrant a) any product, components or parts not manufactured by DPS, b) defects caused by the purchaser's failure to provide a suitable installation environment for the product, c) damage caused by use of the product for purposes other than those for which it was designed, d) damage caused by disasters such as fire, flood, wind or lightning unless and to the extent that the product specification provides for resistance to a defined disaster, e) damage caused by unauthorized attachments or modifications, f) damage during shipment from the purchaser to DPS, or g) any abuse or misuse by the purchaser.

THE FOREGOING WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

In no event will DPS be liable for any special, incidental, or consequential damages based on breach of warranty, breach of contract, negligence, strict tort, or any other legal theory. Damages that DPS will not be responsible for include but are not limited to, loss of profits; loss of savings or revenue; loss of use of the product or any associated equipment; cost of capital; cost of any substitute equipment, facilities or services; downtime; claims of third parties including customers; and injury to property.

The purchaser shall fill out the requested information on the Product Warranty Card and mail the card to DPS. This card provides information that helps DPS make product improvements and develop new products.

For an additional fee DPS may, at its option, make available by written agreement only an extended warranty providing an additional period of time for the applicability of the standard warranty.

## Technical Support

If a purchaser believes that a product is not operating in substantial conformance with DPS' published specifications or there appear to be defects in material and workmanship, the purchaser should contact our technical support representatives. If the problem cannot be corrected over the telephone and the product and problem are covered by the warranty, the technical support representative will authorize the return of the product for service and provide shipping information. If the product is out of warranty, repair charges will be quoted. All non-warranty repairs receive a 90-day warranty.

# Free Tech Support is Only a Click Away

Need help with your alarm monitoring? DPS Information Services are ready to serve you ... in your email or over the Web!

[www.DpsTelecom.com](http://www.DpsTelecom.com)



## Free Tech Support in Your Email: The Protocol Alarm Monitoring Ezine

The Protocol Alarm Monitoring Ezine is your free email tech support alert, delivered directly to your in-box every two weeks. Every issue has news you can use right away:

- Expert tips on using your alarm monitoring equipment — advanced techniques that will save you hours of work
- Educational White Papers deliver fast informal tutorials on SNMP, ASCII processing, TL1 and other alarm monitoring technologies
- New product and upgrade announcements keep you up to date with the latest technology
- Exclusive access to special offers for DPS Telecom Factory Training, product upgrade offers and discounts

To get your free subscription to The Protocol register online at [www.TheProtocol.com/register](http://www.TheProtocol.com/register)

## Free Tech Support on the Web: MyDPS

MyDPS is your personalized, members-only online resource. Registering for MyDPS is fast, free, and gives you exclusive access to:

- Firmware and software downloads and upgrades
- Product manuals
- Product datasheets
- Exclusive user forms

Register for MyDPS online at [www.DpsTelecom.com/register](http://www.DpsTelecom.com/register)

**The Protocol Alarm Monitoring Ezine**  
May 10, 2005 Call: 1-888-393-1060 DPS Telecom

**White Paper: 5 Steps to Intelligent SNMP-Legacy Integration**  
Learn how to make your current alarm monitoring equipment compatible with any SNMP manager — without losing time, money or functionality. [Download White Paper](#)

**Turbocharge Your NetGuardian With SNMP v2c**  
The new NetGuardian 4.0 firmware adds SNMP v2c support, robust message delivery via SNMP INFORM command, customizable alarm severity levels and alarm point grouping, plus a whole lot more. Get the full details on everything that's new and how you can upgrade to NetGuardian 4.0. [Read Full Story](#)

**Creative Solution: Convert Your LEDs to Contact Closures**  
Ted Van Tuyl of Click! Network created a unique monitoring application that converts LEDs to contact closures, using DPS equipment. [Read Full Story](#)

**DPS Telecom** Call: 1-800-693-0351

Home Request Info About Us Applications Products Services Support Knowledge News Meeting Rooms

**Network Alarm Monitoring Fundamentals**  
Alarm Monitoring — Where Do You Start?  
You've just been put in charge of purchasing, selecting or recommending a new network alarm system for your company. Where do you start? What alarm equipment do you need? What monitoring features are essential, and which can you live without? How can you make sure your network is fully protected, without spending too much on equipment you won't use?  
This White Paper is a quick guide to how you can answer these questions for yourself. This paper will NOT tell you, "Just buy this system and everything will be fine." Every network is different. A one-size fits-all system won't provide the specific coverage you need and may cost more money than you really need to spend.  
[Download This White Paper Now!](#)

**Magazine Sign-up**  
Name: \_\_\_\_\_  
E-mail: \_\_\_\_\_  
[Subscribe](#)  
View past issues  
Subscription options

Remember that we'll NEVER sell your email address to anybody, and that's a promise! We will also send you our informative eMagazine.

